



HS2016/2032/2064/2128 Alarm Panel

V1.0 User Manual



WARNING: This manual contains information on limitations regarding product use and function and information on the limitations as to liability of the manufacturer. The entire manual should be carefully read.

Table of Contents

1 Quick Reference	6
2 Understanding your Keypad Display	7
2.1 Icon and LED Keypad Symbols	7
2.2 Keypad Models	8
3 About your Security System	9
3.1 The PowerSeries Neo Security System	9
3.1.1 General System Operation	9
3.1.2 Carbon Monoxide Detection	9
3.1.3 Fire Detection	9
3.1.4 Testing your System	10
3.1.5 Monitoring	10
3.1.6 Maintenance	10
4 Securing the Premises	11
4.1 Arming the System with the Keypad	11
4.1.1 Away Arming the System with the Keypad	11
4.1.2 Stay Arming the System with the Keypad	12
4.1.2.1 Silent Exit Delay	12
4.1.3 Night Arming the System with the Keypad	12
4.1.4 No-Entry Arming	13
4.1.5 Leaving when the System is Already Armed - Quick Exit	14
4.1.6 Exit Delay Time Restart	14
4.2 Arming the system with a 2-way wireless key	14
4.3 Arming the system with a Proximity tag	14
4.4 Bypassing Zones	14
4.4.1 Bypass Groups	17
4.5 Arming Errors and Exit Faults	17
4.5.1 Arming Errors	18
4.5.2 Audible Exit Faults	18
4.6 Disarming the System	18
4.6.1 Disarming Error	19
5 Emergency Keys and Alarms	20
5.1 Emergency Keys	20
5.2 Alarms	20
5.2.1 Fire Alarm	20
5.2.2 Carbon Monoxide Alarm - 4 beeps, long pause, 4 beeps	20
5.2.3 Intrusion (Burglary) Alarm - Continuous Siren	21
5.2.4 Alarm Cancel Window	21
5.3 Resetting Smoke Detectors	21
5.4 Viewing Alarms in memory	21
5.4.1 Alarm Messages	21

Table of Contents

6	Wireless Keys and other Devices	23
6.1	Using 2-way Wireless Keys	23
6.2	Using Proximity Tags	23
6.3	SMS Command and Control	23
6.3.1	Using the Keypad to Lookup the Number to Call for SMS Commands	24
6.3.2	Sending SMS Commands to your System	24
6.3.3	SMS Responses from your System	25
7	Managing Users	26
7.1	Access Code Types	26
7.1.1	Adding, Changing and Deleting Access Codes	27
7.1.2	Enrolling and Deleting Proximity Tags	28
7.1.3	Naming a User	28
7.1.4	Assigning a Partition to a User code	29
7.2	Configuring additional User Options	29
8	Configuring User Functions	30
8.1	User Functions	30
8.1.1	Event Buffer	30
8.1.2	Setting the Time and Date	30
8.1.3	Enabling/Disabling the Auto Arm/Disarm Feature	31
8.1.4	Setting the Auto Arm Time	31
8.1.5	Allowing the Installer to Service your System Remotely - DLS	31
8.1.6	User Callup	32
8.1.7	Late to Open	32
8.1.8	Changing the Brightness of the LCD keypad	33
8.1.9	Changing the Contrast of the LCD keypad	33
8.1.10	Setting the Buzzer volume	33
8.1.11	Setting the Voice Prompt volume	33
8.1.12	Setting the Voice Chime volume	34
9	Managing Troubles	35
9.1	Trouble Conditions	35
10	Managing Partitions	38
10.1	Partitions	38
10.1.1	Single Partition Operation	38
10.1.2	Loaning a Keypad to Another Partition	38
10.2	Fire and CO Zone Types	39
11	Additional Features	40
11.1	Turning the Chime ON/OFF	40
11.2	Audio Verification	40
11.3	Visual Verification	40
11.3.1	System Lockout due to Invalid Attempts	40

Table of Contents

11.4	Command Outputs.....	40
11.5	Cross Zoning.....	41
11.6	Swinger Shutdown.....	41
11.7	Call Waiting.....	41
11.8	Fire Alarm Verification	41
12	Regulatory Agency Statements	42
13	Installer Warning	44
14	Safety Instructions	45
14.1	Regular Maintenance and Troubleshooting.....	45
14.1.1	Cleaning.....	45
14.1.2	Troubleshooting.....	45
15	EULA	46
16	Locating Detectors and Escape Plan	47
16.1	Smoke Detectors.....	47
16.2	Fire Escape Planning	48
16.3	Carbon Monoxide Detectors.....	48
17	Reference	49
17.1	System Information	49
17.2	Service Contact Information.....	49
17.3	Access Code and Sensor / Zone information.....	50

1 Quick Reference

The PowerSeries Neo Alarm System uses shortcut keys to access options or features on all models of keypads. When using an LCD keypad, the PowerSeries Neo Alarm System additionally uses a menu based navigation system. The scroll keys can be used to [Scroll] through the list of options contained within the current menu. For more information on keypads see 2 “Understanding your Keypad Display”. Lookup detailed information on any of the listed actions using the accompanying Section number.

NOTES: Some features must be enabled by installer.

Bypass Groups are not permitted in UL listed installations.

[*] - If configured by installer

Status Lights		Function Keys		Emergency Keys	
	Ready - Indicates system normal. Must be on to arm system. All zones must be secured or bypassed and the system disarmed for this light to activate.		Stay Arm		Fire Alarm
	Armed - Indicates system is armed. If the Ready light and the Armed light are both on, an Exit Delay is in progress.		Away Arm		Medical Alarm
	Trouble - On indicates a system malfunction or tamper. Flashing indicates that the keypad has a low battery condition. Follow the instructions displayed or enter [*][2] to view trouble. Correcting the trouble turns off the indicator.		Chime		Panic Alarm
	AC Power - Indicates AC Power is present. The AC Power light will turn off when AC is absent.		Reset Sensors		
			Quick Exit		
Action	Press			Section	
Arming and Disarming					
Away Arm	for 2 seconds + [Access Code*]			4.1.1	
Stay Arm	for 2 seconds + [Access Code*]			4.1.2	
Night Arm	When armed in stay mode + [Access Code*]			4.1.3	
Disarm	[Access Code]			4.6	
No-Entry Arming	+ [Access Code*]			4.1.4	
Quick Arm/Quick Exit				4.1.1	
Abort Arming Sequence	[Access Code]				
Bypassing - All bypass commands begin with + [Access Code*]					
Bypass Individual Zones	[3 Digit Zone #]			4.4	
Bypass All Open Zones				4.4	
Recall Last Bypass				4.4	
Clear Bypass	OR [Scroll] Bypass Options + + [Scroll] Clear Bypasses +			4.4	
Program Bypass Group	[3 digit zone #s] + OR [3 digit zone #s] + [Scroll] Bypass Options + + [Scroll] Prg Bypass Group +			4.4.1	
Load Bypass Group	OR [Scroll] Bypass Options + + [Scroll] Bypass Group +			4.4.1	
Common Functions					
Set Time and Date	[Master Code] +			8.1.2	
Turn Chime ON/OFF	+ [Access Code*] OR			8.1	
Change Brightness	[Master Code] + +			8.1.8	
Change Contrast	[Master Code] + +			8.1.9	
Add/delete User	+ [Master Code] + [Access Code] +			7.1.1	
Reset Smoke Detectors	OR			5.3	
View Troubles	+ [Access Code*] +			9.1	
View Alarms	+ [Access Code*] +			5.4	
Perform System Test	+ [Master Code] + +			3.1.4	
Buzzer Volume	+ [Master Code] + +			8.1.10	


2 Understanding your Keypad Display

The PowerSeries Neo Alarm System supports a variety of wireless, hardwired and proximity sensor LCD, LED and Icon keypads. All keypads come equipped with the LED status lights described in section 1 "Quick Reference". HS2LCD series keypads display system messages on their LCD screen. HS2ICN series keypads display messages as described in 2.1 "Icon and LED Keypad Symbols". HS2LED series keypads display messages via a series of numbered LEDs as described in 2.1 "Icon and LED Keypad Symbols".


All keypad versions will have a solid blue LED bar that is always on steady except when, if enrolled, a proximity tag is presented to and successfully read by the keypad.

2.1 Icon and LED Keypad Symbols

HS2ICN Series



HS2LED Series



- | | |
|-------------------------------|---|
| 1 Clock Digits 1, 2 | These two 7 segment clock digits indicate the hour digits when the local clock is active, and identify the zone when the OPEN or ALARM icons are active. These two digits scroll one zone per second from the lowest zone number to the highest when scrolling through zones. |
| 2 : (Colon) | This icon is the hours/minutes divider and will flash once per second when the local clock is active. |
| 3 Clock Digits 3, 4 | These two 7 segment displays are the minute digits when the local clock is active. |
| 4 1 to 8 | These numbers identify troubles when   is pressed. |
| 5 Memory | Indicates that there are alarms in memory. |
| 6 Bypass | Indicates that there are zones bypassed. |
| 7 Program | Indicates that the system is in Programming mode, or the keypad is busy. |
| 8 Away | Indicates that the panel is armed in the Away Mode. |
| 9 Fire | Indicates that there are fire and/or CO alarms in memory. |
| 10 Stay | Indicates that the panel is armed in the Stay Mode. |
| 11 Chime | This icon turns on when the Chime function key is pressed to enable Door Chime on the system. It will turn off when the chime function key is pressed again to disable Door Chime. |
| 12 OPEN | This icon is used with clock digits 1 and 2 to indicate activated zones (not alarm) on the system. When zones are opened, the OPEN icon will turn on, and 7 segment displays 1 and 2 will scroll through the violated zones. |
| 13 AC | Indicates that AC is present at the main panel. |
| 14 System Trouble | Indicates that a system trouble is active. |
| 15 Night | Indicates that the panel is armed in the Night Mode. |
| 16 Ready Light (green) | If the Ready light is on, the system is ready for arming. |
| 17 Armed Light (red) | If the Armed light is on, the system has been armed successfully. |

NOTES: For UL listed installations, zones can only be bypassed manually.

2 Understanding your Keypad Display

2.2 Keypad Models

NOTES: In the following list if x = 9 (the system operates in 912-919MHz), x=4 (the system operates in 433MHz band) or x=8 (the system operates in 868MHz band).

Only models operating in 912-919MHz band are UL/ULC listed.

HS2LCD	Alphanumeric LCD keypad
HS2LCDP	Alphanumeric LCD keypad with Prox. Tag support
HS2ICN	Icon keypad
HS2ICNP	Icon keypad with Prox. Tag support
HS2LED	LED keypad
HS2LCDRFx	Alphanumeric LCD keypad with wireless receiver
HS2LCDRFPx	Alphanumeric LCD keypad with wireless receiver and Prox. tag support
HS2ICNRFx	Icon keypad with wireless receiver
HS2ICNRFPx	Icon keypad with wireless receiver and Prox. tag support
HS2LCDWFx	Wireless Alphanumeric LCD keypad
HS2LCDWFPx	Wireless Alphanumeric LCD keypad with Prox. Tag support
HS2LCDWFPVx	Wireless Alphanumeric LCD keypad with Prox. Tag support & Voice Prompting

3 About your Security System

3.1 The PowerSeries Neo Security System

Your PowerSeries Neo has been designed to provide you with the greatest possible flexibility and convenience. Read this manual carefully and have your installer instruct you on how to operate your system and which features have been implemented in your system. All users of this system should be equally instructed in its use. Fill out section 17.1 "System Information" page with all of your zone information and access codes and store this manual in a safe place for future reference.

NOTE: The PowerSeries Neo security system includes specific false alarm reduction features and is classified in accordance with ANSI/ SIA CP-01-2010 Control Panel Standard - Features for False Alarm Reduction. Please consult your installer for further information regarding the false alarm reduction features built into your system as all are not covered in this manual.

3.1.1 General System Operation

Your security system is made up of a PowerSeries Neo control panel, one or more keypads and various sensors and detectors. The control panel will be mounted out of the way in a utility closet or in a basement. The metal cabinet contains the system electronics, fuses and standby battery.

All the keypads have an audible indicator and command entry keys. LED keypads have a group of zone and system status lights. LCD keypads have an alphanumeric liquid crystal display (LCD). The keypad is used to send commands to the system and to display the current system status. The keypad(s) will be mounted in a convenient location inside the protected premises close to the entry/exit door(s).

The security system has several zones of area protection and each of these zones is connected to one or more sensors (motion detectors, glassbreak detectors, door contacts, etc.). A sensor in alarm is indicated by the corresponding zone lights flashing on an LED keypad or by messages on the LCD keypad.

NOTE: Only the installer or service professional shall have access to the control panel.

3.1.2 Carbon Monoxide Detection

This equipment is capable of monitoring carbon monoxide detectors and providing a warning if carbon monoxide is detected. Please read the Family Escape Planning guidelines in this manual and instructions that are available with the carbon monoxide detector.

NOTES: Must be enabled and configured by installer.

The equipment should be installed in accordance with NFPA 720.

3.1.3 Fire Detection

This equipment is capable of monitoring fire detection devices such as smoke detectors and providing a warning if a fire condition is detected. Good fire detection depends on having adequate number of detectors placed in appropriate locations. This equipment should be installed in accordance with NFPA 72 (N.F.P.A., Batterymarch Park, Quincy MA 02269). Carefully review the Family Escape Planning guidelines in this manual.

NOTE: Must be enabled and configured by installer.

3 About your Security System

3.1.4 Testing your System

Tests all system keypad LED's, keypad sounders, bells and/or sirens.

- IMPORTANT**
- To insure that your system continues to function as intended, you must test your system weekly.
 - For UL HOME HEALTH CARE listed applications the system shall also be tested weekly without AC power. To remove AC from the control unit, remove the screw from the restraining tab of the plug in adapter and remove the adapter from AC outlet. After completing the test of the unit using only the battery backup source, reconnect the plug in adapter and attach the screw through the restraining tab so that the adapter is securely attached to the outlet.
 - Should your system fail to function properly contact your installation company immediately.
 - All smoke detectors must be tested by your smoke detector installer once per year to ensure proper operation.

To perform a Keypad and Siren Test

1. From the Ready state press **(*)** **(E)** and enter the [Master code] to access User Functions.
2. Press **(0)** **(4)** or use the scroll keys **(<)** **(>)** to navigate to System Test and press **(*)**. The system activates all keypad sounders, bells/sirens and keypad LEDs for two seconds.
3. To go back to the Ready state press **(#)**.

LCD Display

Press (*) for <>
User Functions

Press (*) for <>
System Test

3.1.5 Monitoring

This system is capable of transmitting alarms, troubles & emergency information to a central station. If you initiate an alarm by mistake, immediately call the central station to prevent an unnecessary response.

NOTES: For CP-01 systems, the monitoring function must be enabled by the installer before it becomes functional.

There is a communicator delay of 30 seconds in this control panel. It can be removed, or it can be increased up to 45 seconds, at the option of the end-user by consulting with the installer.

3.1.6 Maintenance

With normal use, the system requires minimum maintenance. Note the following points:

- Do not wash the security equipment with a wet cloth. Light dusting with a slightly moistened cloth should remove normal accumulations of dust.
- Use the system test described in "Testing Your System" to check the battery condition. We recommend, however, that the standby batteries be replaced every 3-5 years.
- For other system devices such as smoke detectors, passive infrared, ultrasonic or microwave motion detectors or glassbreak detectors, consult the manufacturer's literature for testing and maintenance instructions.

4 Securing the Premises

The PowerSeries Neo provides multiple arming modes as described below:

- Away mode** Use when no one in your household will be home. Away mode activates all perimeter and interior sensors in the alarm system.
- Stay mode** Use this mode when you are staying home, but expect someone to use the entrance door later. Stay mode partially activates your alarm system by arming all perimeter sensors and bypassing all interior sensors.
- Night mode** Use when you want the perimeter and interior armed but would like to allow limited movement in your house without activating the alarm. e.g., disable motion sensors in an area containing bedrooms and a washroom. Night mode is similar to Stay mode but only bypasses internal sensors configured as Night Zones.

NOTES: Verify with your alarm company which modes are available on your system.

For SIA FAR listed panels, the Stay Arming Exit Delay will be twice as long as the Away Arming Exit Delay.

Depending on your system configuration, there are multiple methods you can use to arm your system.

You can arm the system using a:

- Keypad (see 4.1 “Arming the System with the Keypad”).
- 2-way wireless key (see 4.2 “Arming the system with a 2-way wireless key”).
- Proximity tag (see 4.3 “Arming the system with a Proximity tag”).

4.1 Arming the System with the Keypad

4.1.1 Away Arming the System with the Keypad

Away mode activates the complete alarm system by:


- Arming all perimeter sensors.
- Arming all interior sensors.

To Arm the System in Away Mode

1. Ensure all windows and doors are closed and that the Ready ✓ indicator is on.




2. To arm using the Away key, press and hold the **Away key**  for 2 seconds and, if required, enter your [access code].




OR

To Quick Arm the system press  .




3. If zones have been bypassed, ICN or LED keypads bypass LED  will light and the bypassed zones #s will be shown. On an LCD keypad a warning appears.




4. After successfully initiating the arming sequence the:

- Armed  indicator turns on.
- Ready ✓ indicator remains lit.
- Exit Delay timer begins counting down.
- Keypad beeps six times, continues beeping once per second until beeping rapidly in the final ten seconds.



5. To cancel the arming sequence, enter your [access code].



4 Securing the Premises

To Arm the System in Away Mode (Continued)

6. Once the exit delay timer expires, thereby arming the system, the:
- Ready ✓ indicator turns off.
 - Armed indicator remains on.
 - Keypad stops sounding.

LCD Display

System Armed in Away Mode

NOTE: The installer configures the exit delay timer and whether or not an access code is required for arming the system.

4.1.2 Stay Arming the System with the Keypad

Stay mode partially activates your alarm system by:

- Arming all perimeter sensors.
- Bypassing all interior sensors.

To Arm the System in Stay mode

1. Ensure all windows and doors are closed and that the Ready ✓ indicator is on.
2. Press and hold the **Stay key** (🏠) for 2 seconds and, if required, enter your [access code]. **Do not leave the premises.**
3. If zones have been bypassed, ICN or LED keypads bypass LED ✖ will light and the bypassed zones #s will be shown. On an LCD keypad a warning appears.
4. After successfully initiating the arming sequence the:
 - Armed 🚪 indicator turns on.
 - Ready ✓ indicator remains lit.
 - Exit Delay timer begins counting down.
5. To cancel the arming sequence, enter your [access code].
6. Once the exit delay timer expires, thereby arming the system, the:
 - Ready ✓ indicator turns off.
 - Armed 🚪 indicator remains on.
 - Bypass or system indicator activates.

LCD Display

Date	Time
JAN 02/13	2:06a

System is Ready to Arm then

Enter Your Access Code

* Warning * Bypass Active

Exit Delay in Progress

System Disarmed No Alarm Memory

System Armed in Stay Mode

4.1.2.1 Silent Exit Delay

If the system is armed using the **Stay key** (🏠) or the No Entry Arming method (✖) (🚪):

- The warning beep is silenced.
- The exit time is doubled for that exit period only (CP-01 versions only).

NOTE: For non CP-01 versions, Standard Exit Time is used.

4.1.3 Night Arming the System with the Keypad

Night mode partially activates the alarm system by:

- Bypassing all internal sensors configured as Night zones.
- Arming all perimeter sensors.

4 Securing the Premises

- Arming all other internal sensors.

Arming the system in Night mode is only possible after the system has first been armed in Stay mode. To access armed interior areas when the system is armed in Night Mode, you must disarm the system.

NOTES: Ensure that your installer has provided you with a list identifying all programmed night zones.

Your installer can configure a function key to arm the panel in Night mode without the system already being armed in Stay mode.

To Arm the System in Night mode

1. If configured, press and hold the **Night Arm** key for 2 seconds.

OR

1. Once the system is armed in Stay mode (Armed  indicator is on) at any keypad press  

OR

press  .

2. If required, enter your [access code]. All interior zones will now be armed, except for devices programmed as Night Zones.

- The Night mode icon  turns on.

LCD Display

Date	Time
JAN 02/13	2:06a

then

Press (*) for <>
Interior Arm

Enter Your
Access Code

then

Interior Has
Been Armed

To gain access to interior areas that are armed during Night mode

- Disarm the system by entering your [access code].

4.1.4 No-Entry Arming

No-Entry Arming arms the system in Stay mode by:

- Removing the Entry Delay from all configured zones.
- Arming all perimeter sensors.
- Bypassing all interior sensors.

An entry through any zone will create an instant alarm.

To No-Entry Arm the System

1. Check that the Ready  indicator is on and your system is ready to be armed.

2. Press   and, if required, enter your [access code].

3. If zones have been bypassed, ICN or LED keypads bypass LED  will light and the bypassed zones #s will be shown. On an LCD keypad a warning appears.

4. After successfully initiating the arming sequence the:

- Armed light  flashes as a reminder that the system is armed and has no entry delay.
- Keypad sounds fast beeps.
- Keypad displays “Exit Delay in Progress”.

5. To cancel the arming sequence, enter your [access code].

6. Once the exit delay timer expires, the system is armed.

LCD Display

Date	Time
JAN 02/13	2:06a

Enter Your
Access Code

* Warning *
Bypass Active

then

Armed With No
Entry Delay

then

Exit Delay in
Progress

System Disarmed
No Alarm Memory

System Armed
in Stay Mode

4 Securing the Premises

4.1.5 Leaving when the System is Already Armed - Quick Exit

Use the Quick Exit feature if the system is already armed and you would like to leave without disarming and rearming the system. Quick Exit uses the same hot keys as Quick Arming, and it provides you with a two minute exit delay to leave the premises without triggering an alarm. Once the door you leave from closes, the exit delay timer will be cancelled.

To Quick Exit

1. When the system is already armed and the Armed light  is lit, press and hold the **Quick Exit** key  for 2 seconds

OR

press  .

2. Exit the premises before the exit delay timer expires. After exiting, the delay timer will be cancelled.

LCD Display

Quick Exit in Progress

4.1.6 Exit Delay Time Restart

The control panel provides an option where, if an entry/exit zone is tripped a second time prior to the end of the exit delay, the exit delay time restarts. The exit delay timer can only be restarted once.

4.2 Arming the system with a 2-way wireless key

If configured, the PowerSeries Neo system can be armed using the following wireless keys:

- PG4929/PG8929/PG9929
- PG4939/PG8939/PG9939

To Arm the System with a 2-way wireless key

- Press the desired Arming mode button anytime the system Ready  indicator is on.

4.3 Arming the system with a Proximity tag

If configured, the PowerSeries Neo system can be armed using MPT proximity tags.

To Arm the System with a Proximity tag

- Present your Proximity tag to a keypad equipped with a proximity sensor anytime the system Ready  indicator is on.
- If configured by your installer, enter your access code.

4.4 Bypassing Zones

WARNING: If a zone is not operating properly contact a service person immediately.

Bypassing zones intentionally unprotects specified zones the next time your system is armed. Depending on the type of keypad, bypassed zones will be identified differently. Using an HS2LCD series keypad, bypassed zones are indicated on the LCD screen as shown in Table 4-1. If using an LED or ICN series keypad, the  will light and the bypassed zones #s will be shown.

4 Securing the Premises

Table 4-1 LCD Keypad Zone Indications

LCD Display		Indication	Description
Zone Label	<>	none	Zone is ready for arming.
Zone Label	<> 0	O	Zone is currently open. You may be unable to arm the system.
Zone Label	<> B	B	Zone is bypassed.

Bypassed zones:

- Must be configured before arming the system.
- Can be done using a keypad or SMS.
- Allow for access to protected areas when the system is armed.
- Allow you to arm the system if a zone is temporarily out of service.
- Reduce the level of security.
- Will not sound an alarm.
- Are automatically cancelled each time the system is disarmed.
- Can be programmed together within bypass groups. For more information see 4.4.1 “Bypass Groups”.

Additional bypass features:

- Recall Last Bypass** Recalls all zones that were bypassed the last time the bypass zone feature was used.
- Bypass All Open Zones** Allows the user to quickly bypass all open zones with a single command.
- Clear Bypass** Instantly clears all zones indicated to be bypassed.
- Programming a Bypass Group** Use when you consistently bypass the same zones. This feature allows you to store in memory one group of bypassed zones per partition.
- Activating a Bypass Group** Loads a stored bypass group from memory.

NOTES: Ensure that no zones are unintentionally bypassed when arming your system.

24-hour zones can only be unbypassed manually.

For security reasons, your installer has programmed the system to prevent you from bypassing certain zones (e.g., smoke detectors). For more information on fire zones see 10.2 “Fire and CO Zone Types”.

To Bypass Individual Zones

1. Press **(*)** to enter the function menu.
2. Press **(*)** or **(1)**. If required enter your [access code].
3. Directly bypass zones by entering their [3 digit zone #]. If using an LCD keypad press **(*)**.

OR

- Scroll to the desired zone using the **(< >)** keys and press **(*)**.
4. To toggle and unbypass a zone reenter the [3 digit zone #] or press **(*)** again. To bypass more zones repeat steps 3 and 4.
 5. To exit bypassing mode press **(#)**.

LCD Display

Press (*) for <>
Zone Bypass

Zone Bypass <>
(*) To Bypass

Zone 1 <>
0

Zone 1 <>
B

4 Securing the Premises

To Bypass Individual Zones (Continued)

6. If using an LED or ICN series keypad, the  will light and the bypassed zone #s will be shown. If the system is ready to arm the Ready  indicator will be lit. When arming the system the following message briefly displays.

LCD Display

* Warning *
Bypass Active

To Bypass All Open Zones

1. Press  to enter the function menu.
2. Press  or . If required enter your [access code].
3. Press   

OR

Scroll to Bypass Options and press . Scroll to Bypass Op. Zones and press .

4. To exit bypassing mode press .
5. If using an LED or ICN series keypad, the  will light and the bypassed zones #s will be shown. If the system is ready to arm the Ready  indicator will be lit. When arming the system the following message briefly displays.

LCD Display

Press (*) for <>
Zone Bypass

Zone Bypass <>
(*) To Bypass

Press (*) for <>
Bypass Op. Zones

* Warning *
Bypass Active

To Recall the Last Bypassed Zones

1. Press  to enter the function menu.
2. Press  or . If required enter your [access code].
3. Press   

OR

Scroll to Bypass Options and press . Scroll to Bypass Recall using the   keys and press .

4. To exit bypassing mode press .
5. If using an LED or ICN series keypad, the  will light and the bypassed zone #s will be shown. If the system is ready to arm the Ready  indicator will be lit. When arming the system the following message briefly displays.

LCD Display

Press (*) for <>
Zone Bypass

Zone Bypass <>
(*) To Bypass

Press (*) for <>
Bypass Recall

then

Bypass Recalled
Zones Bypassed

* Warning *
Bypass Active

To Clear the Bypass Indication from All Zones

1. Press  to enter the function menu.
2. Press  or . If required enter your [access code].
3. Press   

OR

Scroll to Clear Bypasses using the   keys and press . All Bypassed zones will now be open.

4. To exit bypassing mode press .

LCD Display

Press (*) for <>
Zone Bypass

Zone Bypass <>
(*) To Bypass

Press (*) for <>
Clear Bypasses

then

Bypass Cleared
Zones Unbypassed

4 Securing the Premises

4.4.1 Bypass Groups

Program frequently bypassed zones into the system as a bypass group. Using bypass groups avoids individually bypassing each zone. One bypass group can be programmed per partition.

NOTE: This feature is not to be used in UL listed installations.

To Program a Bypass Group

1. Press **(*)** to enter the function menu.
2. Press **(*)** or **(1)**. If required enter your [access code].
3. Enter the [3 digit zone #] of all zones you want bypassed
OR
Scroll to and press **(*)** to indicate all zones you want bypassed.
4. Press **(9)** **(9)** **(5)** to program the bypass group with the currently bypassed zones
OR
Scroll to Bypass Options using the **(←)** **(→)** keys and press **(#)**. Scroll to Prg Bypass Group and press **(*)**.
5. The Bypass Group is now programmed. The keypad will beep three times.
6. To exit bypassing mode and return to the Ready state, press **(#)**.

To Load a Bypass Group

1. Press **(*)** to enter the function menu.
2. Press **(*)** or **(1)**. If required enter your [access code].
3. Press **(9)** **(9)** **(1)**
OR
Scroll to Bypass Options using the **(←)** **(→)** keys and press **(#)**. Scroll to Bypass Group and press **(*)**.
4. The group of zones are now bypassed. The following message briefly displays.
5. To exit bypassing mode and return to the Ready state, press **(#)**.
6. If using an LED or ICN series keypad, the **ⓧ** will light and the bypassed zones #s will be shown. If the system is ready to arm the Ready **✓** indicator will be lit. When arming the system the following message briefly displays.

LCD Display

Press (*) for <>
Zone Bypass

Scroll to <>
Bypass Zones

Upstrs H Wdw <>
B

Press (*) for <>
Prg Bypass Group

Bypass Group
Programmed

System is
Ready to Arm

LCD Display

Press (*) for <>
Zone Bypass

Scroll to <>
Bypass Zones

Press (*) for <>
Bypass Group

Bypass Group
Zones Bypassed

System is
Ready to Arm

* Warning *
Bypass Active

4.5 Arming Errors and Exit Faults

The PowerSeries Neo audibly notifies you of any errors when you are attempting to arm the system or exit the premises.

4 Securing the Premises

4.5.1 Arming Errors

An error tone (long beep) sounds if the system is unable to arm. Arming errors occur if:

- The system is not ready to arm (i.e., sensors are open).
- An incorrect user code is entered.

To Correct an Arming Error

1. Ensure all sensors are secure. Your keypad will identify all open zones.
2. Try arming the system again. For details on arming the system, see one of the previous arming procedures.
3. If errors persist contact your installer.

4.5.2 Audible Exit Faults

NOTE: Must be enabled by installer.

In an attempt to reduce false alarms, the Audible Exit Fault notifies you of an improper exit when arming the system. Improper exits are caused by failing to securely close the Exit/Entry door.

Improper exits cause the following system notifications:

- The keypad emits one continuous beep.
- The bell or siren sounds for the duration of the entry delay until a valid user code is entered or until the programmed Bell time out expires.

To Correct an Exit Fault

1. Re-enter the premises.
2. Disarm the system before the entry delay timer expires by entering your [access code].
3. Follow the Away arming procedure again, making sure to close the entry/exit door properly. For more details see 4.1.1 “Away Arming the System with the Keypad”.

4.6 Disarming the System

Depending on your system configuration, there are multiple methods you can use to disarm your system.

You can disarm the system using a:

- Keypad
- 2-way wireless key
- Proximity Tag

To Disarm the System with a Keypad

- Enter your [access code] anytime the system is armed. (Armed  indicator is on).
- If you walk through the entry door the keypad will beep. Enter your code within _____ seconds to avoid an alarm condition.

To Disarm the System with a 2-way Wireless Key

- Press the disarm button anytime the system is armed. (Armed  indicator is on).
- If you walk through the entry door the keypad will beep. Press the disarm button within _____ seconds to avoid an alarm condition.

NOTE: After disarming a system with an HS2LCD keypad using a 2-way wireless key, always check the alarm memory to determine if any alarms have occurred during the armed period.

4 Securing the Premises

To Disarm the System with a Proximity Tag

- Present your Proximity Tag to a keypad equipped with a proximity sensor anytime the system is armed. (Armed  indicator is on) and if configured as required, enter your access code.
- If you walk through the entry door the keypad will beep. Present your Proximity Tag within _____ seconds to avoid an alarm condition.

NOTE: Duration of Entry timer is programmed by installer.

4.6.1 Disarming Error

If your code is invalid, the system will not disarm and a 2-second error tone will sound. If this occurs, press  and re-enter your access code.

5 Emergency Keys and Alarms

5.1 Emergency Keys

IMPORTANT: EMERGENCY USE ONLY!

Pressing both the emergency keys generates a Fire, Medical, or Panic Alarm, and alerts the monitoring station. e.g., to generate a medical alarm press both of the medical alarm keys   for 2 seconds and the display on an LCD keypad will show Hold down keys for Med. Alarm. The keypad beeps to indicate that the alarm input has been accepted and sent to the monitoring station.



Fire Alarm



Medical Alarm



Panic Alarm

NOTES: Verify with your alarm company that your system is equipped with emergency keys.

Fire keys can be disabled by the installer.

Having an optional audio verification module installed in your system allows the monitoring station to open 2-way communication when notified of an alarm.

5.2 Alarms

The system can generate different alarm sounds, each with a different purpose and priority.

Table 5-1 Alarm Types

Priority	Type of Alarm	What you hear
1	Fire	Temporal (3 beeps then a pause) or pulsed siren (continuous beeping)
2	Carbon Monoxide	4 beeps, 5 second pause, 4 beeps
3	Intrusion (Burglary)	Continuous siren
4	Flood	1 second on, 3 seconds off, repeating

NOTE: Medical alarm is silent, it only results in an alarm transmission to the monitoring station.

5.2.1 Fire Alarm

Follow your emergency evacuation plan immediately!

If the Fire Alarm was Accidental (i.e., burnt toast, bathroom steam, etc.)

1. Enter your Access Code to silence the alarm.
2. Call your central station to avoid a dispatch.

NOTE: Verify with your alarm company that your system is equipped with fire detection.

For information on resetting smoke detectors see 5.3 “Resetting Smoke Detectors”.

5.2.2 Carbon Monoxide Alarm - 4 beeps, long pause, 4 beeps

WARNING: Carefully review your Carbon Monoxide Alarm Installation/User Guide to determine the necessary actions required to ensure your safety and ensure that the equipment is operating correctly. Incorporate the steps outlined in the guide into your evacuation plan.

Activation of your CO alarm indicates the presence of carbon monoxide (CO), which can be fatal. During an alarm:

- The red LED on the CO detector flashes rapidly and buzzer sounds with a repeating cadence of: 4 quick beeps, 5-second pause, 4 quick beeps.
- The siren connected to the control panel produces the same cadence as above.
- The keypad provides audible and visual indication of the CO alarm.

5 Emergency Keys and Alarms

If the Carbon Monoxide Alarm Sounds

1. Operate Silence button.
2. Call emergency services or your fire department.
3. Immediately move outdoors or to an open door/window.

5.2.3 Intrusion (Burglary) Alarm - Continuous Siren



If you are unsure of the source of the alarm approach with caution!

If the Intrusion alarm was accidental

1. Enter your Access Code to silence the alarm. If the code is entered within 30s (or the programmed value of the alarm transmission delay) the transmission of the alarm to the monitoring station will be cancelled.
2. Call your central station to avoid a dispatch.

5.2.4 Alarm Cancel Window

The control panel provides a period of time in which the user can cancel the alarm transmission. The minimum duration of this time is five minutes.

If the programmed alarm transmission delay has expired, cancelling an alarm sends a message to the monitoring station. Upon a successful transmission of the cancellation message the keypad will beep 6 times.

NOTES: Must be enabled and configured by installer.

For CP-01 systems, alarm transmission delay must not exceed 45 seconds.

5.3 Resetting Smoke Detectors

After having detected an alarm condition smoke detectors require a reset to exit the alarm condition.

NOTE: Verify with your alarm company if this function is required on your system.

To Reset the Sensors

- Press and hold  on the keypad for 2 seconds. If the reset is successful, the alarm is cancelled.
- If a smoke detector fails to reset, it may still be detecting an alarm condition. If unsuccessful, the alarm will reactivate or continue.

5.4 Viewing Alarms in memory

When an alarm occurs the keypad indicator illuminates. Viewing the Alarm memory provides more information on the sensor(s) that were tripped. When using a ICN or LED keypad the Memory LED  will be lit and the zone numbers will be displayed.

To View Alarms in Memory

- Press  

OR

use the scroll keys   to navigate to Alarm Memory and press  .
The Alarm information will display. For more information on the messages that could be displayed see 5.4.1 “Alarm Messages”.

LCD Display

Press (*) for <> Alarm Memory

5.4.1 Alarm Messages

LCD Display

Burglary Verified

What it means

Multiple burglary sensors were tripped. Central station has been notified.

5 Emergency Keys and Alarms

LCD Display

What it means

Burglary Not
Verified <>

A single burglary sensor was tripped. Central station has been notified.

Fire Alarm
Fire Zone 1 <>

Fire alarm has been triggered. Central station has been notified. On an ICN or LED keypad the 🔥 will be lit.

CO Alarm
CO Zone 1 <>

CO alarm has been triggered. Central station has been notified. On an ICN or LED keypad the 🔥 will be lit.

6 Wireless Keys and other Devices

In addition to the keypad, the PowerSeries Neo system can be controlled using a variety of devices:

- 2-way wireless keys
- Proximity Tags
- via SMS using a cellphone.

6.1 Using 2-way Wireless Keys

2-way wireless keys allow users in the close proximity of their house the ability to readily arm/disarm their system, and to call for help. For information on enrolling wireless keys see 7.1.3 "User Labels (LCD keypads only)".




Figure 6-1 PG4929/PG8929/PG9929

- 1 Away arm
- 2 Stay arm
- 3 Disarm
- 4 Panic
- 5 Command Output 1
- 6 Message LED
- 7 Status LEDs




Figure 6-2 PG4939/PG8939/PG9939

- 1 Away Arm
- 2 Stay Arm
- 3 Disarm
- 4 Panic
- 5 Command Output 1
- 6 LED

NOTES: Panic feature has not been evaluated by UL.

All wireless key buttons are programmable. Verify the functions assigned to each key with your installer.

When using compatible wireless keys there is one bell squawk for arming and two bell squawks for disarming.

6.2 Using Proximity Tags

The MPT proximity tag is ideal for people who have difficulties remembering codes or who do not interact with the system regularly. To operate properly, Proximity tags must be enrolled in the system. The LED Bar flashes 3 times upon a valid Prox Tag being read by the keypad successfully. If the Proximity Tag is invalid, the LED Bar will stay ON and an error tone will sound.

For more information see 7.1.2 "Enrolling and Deleting Proximity Tags".

6.3 SMS Command and Control

SMS Command and Control allows you to send text messages to your system, enabling the system to perform certain actions. For a list of commands and how to send them see Table 6-1. As a security measure, only phone numbers configured by your installer will be permitted to contact your system. Messages from all other phone numbers will be rejected.

NOTES: This is a supplementary feature that has not been investigated by UL/ULC.

Must be enabled and configured by installer. Only supported with an LCD keypad.

6 Wireless Keys and other Devices

6.3.1 Using the Keypad to Lookup the Number to Call for SMS Commands

The phone number of the system is programmed by the installer. To quickly find the phone number perform the following steps.

To find the System's Phone Number

1. Check that the Ready ✓ indicator is on and the system is disarmed.

LCD Display

Date	Time
JAN 02/13	2:06a

2. Press ***** **6**

OR

press ***** and use the scroll keys **<** **>** to navigate to User Functions
press ***** and enter [Master Code].

Press (*) for <> User Functions

3. Press **1** **1** or use the scroll keys **<** **>** to navigate to SMS Programming and press *****

Press (*) for <> SMS Programming

4. Scroll **<** **>** to navigate to SMS Programming and press *****. The phone number to send your SMS commands to displays.

Press (*) for <> GSM Phone No.

6.3.2 Sending SMS Commands to your System

In order to successfully send commands to your system from your cellphone, you must send SMS messages in the proper format. If configured, commands require the inclusion of a User Access Code in your message. The access code will be verified by the system before executing any commands.

Additional information about sending SMS commands:

- Text messages are not case sensitive and extra spaces are ignored.
- In multi-partition systems and if the User has rights to manage the desired partitions, commands can be sent to specific partitions by including the partition number. For more information on partitions see section 10 "Managing Partitions".
- If the panel is configured to require an Access Code and the code is not sent or is invalid, the panel will send a notification to the user advising the command was unsuccessful.

Table 6-1 lists all available SMS commands with examples of how to enter the Partition number and access codes. The format for entering commands is as follows:

Command	Partition number	Access Code
Stay Arm	001	1234

NOTES: Verify with your installer that the Partition number and access code are required in your SMS message. If one or both are not required, do not enter them in your SMS message.

Responses to Status and Alarm Memory requests may require more than 1 SMS message, depending on status of the system. There is a 10 second delay between transmission of SMS messages.

Table 6-1 SMS Commands

Commands	Notes
Stay Arm	Stay arms the system
Away Arm	Away arms the system
Night Arm	Night arms the system
Disarm	Disarms the system
Activate Command Output 1	Activates Output 1

6 Wireless Keys and other Devices

Table 6-1 SMS Commands (Continued)

Commands	Notes
Activate Command Output 2	Activates Output 2
Activate Command Output 3	Activates Output 3
Activate Command Output 4	Activates Output 4
Deactivate Command Output 1	Deactivates Output 1
Deactivate Command Output 2	Deactivates Output 2
Deactivate Command Output 3	Deactivates Output 3
Deactivate Command Output 4	Deactivates Output 4
Bypass 001	Bypasses specified zone number
Unbypass 001	Clears the bypass from the specified zone number
Status Request	Omitting the partition number causes the system to send a status report for all partitions. To request a status report for a specific partition enter the appropriate partition number.
Alarm Memory Request	Omitting the partition number causes the system to send a status report for all partitions. To request a status report for a specific partition enter the appropriate partition number.
Help	The Help command generates an SMS response listing all Interactive commands that can be sent to the module. Access Code is not required.

6.3.3 SMS Responses from your System

SMS responses are sent to the phone that initiated the command.

Table 6-2 System SMS Responses

System Response	Notes
Successful	Sent when a command and control function is successfully performed by the panel.
Unsuccessful	Sent when a command and control function not successfully performed by the panel.
Invalid Command	Sent when a command sent was not accepted as valid by the system.
System Stay Armed	Sent in response to a status request and if a partition is stay armed.
System Away Armed	Sent in response to a status request and if a partition is away armed.
System Night Armed	Sent in response to a status request and if a partition is night armed.
System Disarmed Ready	Sent in response to a status request and if a partition is disarmed and ready to arm.
System Disarmed Not Ready	Sent in response to a status request and if a partition is disarmed and is not ready to arm.
System is in Alarm	Sent in response to a status request and if a partition is in alarm.
Service is Required	Sent in response to a status request and if a partition is in trouble.
No Alarm Memory	Sent in response to a alarm memory request and there are no alarms in memory.

7 Managing Users

Up to 95 different user access codes can be programmed in the PowerSeries Neo. Each user access code can be:

- Uniquely labeled.
- Assigned a proximity tag. In order to operate, proximity tags must be enrolled in the system.
- Assigned to only operate specific partitions. For more information on partitions see section 10 "Managing Partitions".
- Configured with additional attributes. For more information see 7.2 "Configuring additional User Options".

NOTE: Your installer configures all access codes to be either 4 or 6 digits. You cannot have access codes of both lengths on your system.

Programed zones are indicated on the LCD screen. For more information on user flags see Table 7-1. On an ICN or LED keypad programmed users will have their digits displayed.

Table 7-1 User Indications

LCD Display	Indications	Description
User Code 01 -	-	Unprogrammed code.
User Code 01 P	P	Programmed code.
User Code 01 T	T	Code and tag/key are programmed.

7.1 Access Code Types

The alarm system provides the following user access code types:

Code	Add User	Delete User	Arm	Disarm	Access Codes	User Functions	Installer
Master	All	All	Yes	Yes	Yes	Yes	No
User	No	No	Yes	Yes	No	No	No
Supervisor	All but Master	All but Master	Yes	Yes	Yes	Yes	No
Duress	No	No	Yes	Yes	No	No	No
One-time user	No	No	Yes	1/day	No	No	No

Installer and Master code are system codes that can be changed but not deleted. The other codes are user-defined and can be added or deleted as necessary. By default, access codes have the same partition and attribute programming as the code used to program them.

- Master Code** By default the master code can access all partitions and can perform any keypad function. This code can be used to program all access codes, including the supervisor and duress codes. The master code is code # [01].
- User Codes** This type of access code is used to arm and disarm assigned partitions and can access the User Functions menu.
- Supervisor Codes** Use when you want to allow additional users to manage Access Codes [*5] or User Functions[*6]. Supervisor codes created by the master code will have the same attributes as the master code. Supervisor codes created by another supervisor code will have the same attributes, except the supervisor attribute. Must be assigned manually afterwards. After creation, attributes can be changed for all supervisor codes. For information on how to program a supervisor code see 7.2 "Configuring additional User Options".

7 Managing Users

Duress Codes

Use if forced to access your keypad under threat. Duress codes function the same as user access codes, except they transmit a Duress Report to your monitoring station when used to perform any function on the system.

Duress codes cannot be used to access Access Codes[*5], User Functions[*6] or Installer[*8] menus. For information on how to program a Duress Code see 7.2 "Configuring additional User Options".

One Time User Code

Use when needing to grant someone one time access to your home once per day, i.e., a cleaning person or contractor. The ability to disarm the system is reset at midnight or when the one time user code is keyed in by the master code user. For information on how to program a One Time User Code see 7.2 "Configuring additional User Options".

To open the Access Codes Menu

1. Press

OR

press and use the scroll keys to navigate to Access Codes and press .

2. Enter [Master or supervisor code].

3. Enter [2 digit user #]

OR

scroll through the list of users and press . On an LED keypad the user number will begin flashing.

4. To go back to the Ready state press .

LCD Display

Press (*) for <>
User Functions

Enter Master
Access Code

Press (*) for <>
(User Label)

7.1.1 Adding, Changing and Deleting Access Codes

Each configured user is assigned a number from 01-95. Access codes cannot be duplicated.

To Add or Change User Access Codes

1. From the desired user press or

2. Enter a new 4 or 6 digit access code. After entering a new code you will be automatically returned to the previous menu, and on an LCD display the flag is changed to P from -. On an ICN or LED keypad the programmed user will have their digits displayed. If a duplicate code is entered the error tone will sound.

LCD Display

Press (*) for <>
Access Code

Enter New Code
XXXXXX

then

Press (*) for <>
User Code 03 P

To Delete a User Access Code

1. From the desired user press or

2. Press . The code is deleted, and you are returned to the previous screen. The flag is changed to - from P. On an ICN or LED keypad the programmed user's digits will cease being displayed.

LCD Display

Press (*) for <>
Access Code

Enter New Code
030516

then

(*) to Edit <>
User Code 03 -

NOTE: Any proximity tags associated with deleted user codes will need to be re-enrolled.

7 Managing Users

7.1.2 Enrolling and Deleting Proximity Tags

When enrolling or deleting proximity tags for a user, the system provides a choice of option depending on if tag is already enrolled or not. For more information on see 6.2 "Using Proximity Tags".

To Enroll a Proximity Tag

1. From the desired user press **2** or **< >** scroll to Prox Tag and press *****.
2. If no tag is enrolled for this user you will be asked to present the tag to the reader.
 - If the card successfully enrolls the blue LED bar flashes.
 - If the tag is invalid the following message is displayed.
 - If the tag already is enrolled with another user the following message is displayed.

LCD Display

```
Press (*) for <>
Prox Tag
```

```
Present Tag or
Press # to Exit
```

```
Tag Enrolled
Successfully
```

```
Invalid Tag
Not Enrolled
```

```
Duplicate Tag
Not Enrolled
```

To Delete a Proximity Tag

1. From the desired user press **2** or **< >** scroll to Prox Tag and press *****.
2. If a tag is enrolled for this user you will be asked if you would like to delete the Tag. Press ***** to delete the tag.

LCD Display

```
Press (*) for <>
Prox Tag
```

```
* To Delete Tag
Press # to Exit
```

```
Tag Deleted
Successfully
```

7.1.3 Naming a User

Adding or editing labels are accomplished by using the keypad to input the desired letters or numbers. Figure 7-1 depicts the three letters and one number that corresponds to each keypad button. The first press of the number key displays the first letter. The second press displays the second letter, etc.

1	2	3
A, B, C, 1	D, E, F, 2	G, H, I, 3
4	5	6
J, K, L, 4	M, N, O, 5	P, Q, R, 6
7	8	9
S, T, U, 7	V, W, X, 8	Y, Z, 9,0
	0	
	Space	

Figure 7-1 Entering letters using the keypad

To Edit a User Label

1. From the User Codes menu press **4** or scroll **< >** to User Labels and press *****.
2. Use the arrow keys **< >** to move the cursor to a blank space or existing character.
3. Press the number key corresponding to the appropriate letter as shown in Figure 7-1.

LCD Display

```
Press (*) for <>
User Labels
```

```
Program Name
{User 1 Label}
```

7 Managing Users

To Edit a User Label

LCD Display

- When the required letter or number is displayed use the arrow keys (< >) to scroll to the next letter.
- When finished, press the (*) key, use the (< >) keys to scroll to Save then press (*).

7.1.4 Assigning a Partition to a User code

User codes can be configured to have access only to specific partitions. For more information see section 10 "Managing Partitions".

NOTE: Partitions are configured by your installer.

To Assign a Partition to a User code

LCD Display

- From the desired user press (4) or (< >) scroll to Partition Assign and press (*).
- Press (*) to toggle assigning, Y or N, the partition to the user.

OR

If using an LED or ICN keypad press the [partition #].

Press (*) for <>
Partition Assign

(<*) To Toggle <>
<Partition Lb> Y

7.2 Configuring additional User Options

Users can also be assigned the following options:

- [1] Supervisor Code** For more information see 7.1 "Access Code Types".
- [2] Duress Code** For more information see 7.1 "Access Code Types".
- [3] Zone Bypass** Grants the user the ability to bypass zones.
- [4] Remote Access** Grants the user the ability to use SMS features. For more information see 6.3 "SMS Command and Control"
- [7] Bell Squawk** Use to generate a bell squawk when arming/disarming the system.
NOTE: When using wireless keys to arm/disarm the system there will be:
 - one bell squawk for arming
 - two bell squawks for disarming.
 - three squawk pairs when disarming with an alarm in memory.
- [8] One Time Use** For more information see 7.1 "Access Code Types".

To Configure additional User Options

LCD Display

- From the desired user press (5) or (< >) scroll to User Options and press (*).
- Use the (< >) keys to cycle through the User Options and press (*) to toggle configuring the displayed option.

OR

- If using an LED or ICN keypad press the [feature number as listed above].

Press (*) for <>
User Options

(<*) To Toggle <>
Bell Squawk Y

8 Configuring User Functions

8.1 User Functions

The PowerSeries Neo allows for a variety of user configurable functions as listed below:

- Event Buffer
- Auto Arm Time
- Late To Open
- Contrast Control
- Time and Date
- System Service/DLS
- Late To Open Time
- Buzzer Control
- Auto Arm/Disarm
- User Call-up
- Brightness Control

NOTES: User Functions can only be modified when the system is disarmed.

To access the User Function menu

1. Press ***** **6**

OR

press ***** and use the scroll keys **<** **>** to navigate to User Functions and press *****.

2. Enter Master code and scroll through the options listed above.

3. To go back to the Ready state press **#**.

LCD Display

Press (*) for <>

User Functions

Enter Master
Access Code

then

Select Option <>
Event Buffers

8.1.1 Event Buffer

The Event Buffer displays a list of the last 1000 events on your system. You may only view the event buffer using an LCD keypad.

To view the Event Buffer

1. From the User Function menu **<** **>** scroll to Event Buffer and press *****.

2. Press **<** **>** to scroll through the Event Buffer. When finished press **#** to return to the Ready state.

LCD Display

Select Option <>
Event Buffer

000X-Message
Time/Date

8.1.2 Setting the Time and Date

To set the Time and Date

1. From the User Function menu use the shortcut key **0** **1** or press **<** **>** to scroll to Time and Date and press *****.

2. Use the number keys to set the time and date. When finished press **#** to return to the Ready state.

LCD Display

Select Option <>
Time and Date

HH:MM MM/DD/YY
11:12 01/14/13

8 Configuring User Functions

8.1.3 Enabling/Disabling the Auto Arm/Disarm Feature

NOTE: Access to this feature must be configured by installer.

To enable/disable Auto Arm/Disarm

1. From the User Function menu use the shortcut key **0** **2** or press **<** **>** to scroll to Auto Arm/Disarm.
2. Press ***** to enable/disable the Auto Arm/Disarm feature.
3. When finished press **#** to return to the Ready state.

LCD Display

Press (*) for <>
Auto Arm/Disarm

Auto Arm/Disarm
is Enabled

OR

Auto Arm/Disarm
is Disabled

8.1.4 Setting the Auto Arm Time

The system can be configured to Auto arm at a specific time on each day of the week. If a specific time is not configured for a day of the week the system will not arm automatically on that day.

NOTE: Access to this feature must be configured by installer.

To set the Auto Arm Time

1. From the User Function menu use the shortcut key **0** **3** or press **<** **>** to scroll to Auto Arm Time.
2. Press ***** to open a days of the week sub menu. Scroll the days of the week and press ***** to set the time for that day.

OR

If using an ICN or LED keypad to select the desired day press [1-7] where 1=Sunday and 7=Saturday.

3. Using a 24 hour format, set the desired time. After you enter the fourth digit the screen will revert back to the previous day of the week menu. Entering the time 9999 disables the late to open feature for that day. When using an ICN or LED keypad the time will not display.
4. Continue setting the time for the desired days of the week. When finished press **#** to return to the Ready state.

LCD Display

Press (*) for <>
Auto Arm Time

Press (*) for <>
Sunday

Set 24Hr Time
Enter HH:MM 9999

Set 24Hr Time
Enter HH:MM 9999

NOTE: If you set an invalid time the error tone will sound.

8.1.5 Allowing the Installer to Service your System Remotely - DLS

Occasionally, your installer may need to remotely access the Installer programming of your security system using Downloading Software (DLS). In order for this to successfully occur, you may need to manually allow access to your system.

NOTE: Access to this feature must be configured by installer.

To enable/disable the System Service/DLS

1. From the User Function menu use the shortcut key **0** **5** or press **<** **>** to scroll to SystemServ/DLS.

LCD Display

Press (*) for <>
SystemServ/DLS

8 Configuring User Functions

To enable/disable the System Service/DLS (Continued)

2. Press ***** to enable/disable the SystemServ/DLS feature.
3. When finished press **#** to return to the Ready state.

LCD Display

SystemServ/DLS
is Enabled

or

SystemServ/DLS
is Disabled

8.1.6 User Callup

Using DLS, User Call-up allows your system to make one attempt to connect to the installer's remote computer. For a successful connection, the remote computer must be waiting for the system's call.

NOTE: Access to this feature must be configured by installer.

To perform a User Callup

1. From the User Function menu use the shortcut key **0** **6** or press **<** **>** to scroll to User Callup.
2. When finished press **#** to return to the Ready state.

LCD Display

Press (*) for <>
User Callup

8.1.7 Late to Open

Typically used to track children after school, the Late to Open feature allows you to be notified if your alarm system is not disarmed by a programmed time of day.

For example, if you arrive from work at 5pm, and your child arrives home at 4 p.m. you could set the programmable time for 4:15 p.m. If the system is not disarmed by 4:15 an alert would be sent to the monitoring station and an event will be stored in the event buffer viewable from an LCD keypad. If SMS notifications are configured for your system the monitoring station will notify you via SMS message. For more information see 8.1.1 "Event Buffer".

NOTE: Access to this feature must be configured by installer.

To enable/disable Late to Open

1. From the User Function menu use the shortcut key **0** **9** or press **<** **>** to scroll to Late to Open.
2. Press ***** to enable/disable the Late to Open feature.
3. When finished press **#** to return to the Ready state.

LCD Display

Press (*) for <>
Late to Open

Late to Open
is Enabled

or

Late to Open
is Disabled

To set the Late to Open time

1. From the User Function menu use the shortcut key **1** **0** or press **<** **>** to scroll to Late to Open Time.
2. Press ***** to open a days of the week sub menu. Scroll the days of the week and press ***** to set the time for that day.

LCD Display

Press (*) for <>
Late to Open Time

Press (*) for <>
Sunday

OR

If using an ICN or LED keypad to select the desired day press [1-7] where 1= Sunday and 7=Saturday.

8 Configuring User Functions

To set the Late to Open time (Continued)

- Using a 24 hour format, set the desired time. After you enter the fourth digit the screen will revert back to the previous day of the week menu. Entering the time 9999 disables the late to open feature for that day. When using an ICN or LED keypad the time will not display.
- Continue setting the time for the desired days of the week. When finished press **#** to return to the Ready state.

LCD Display

```
Set 24Hr Time
Enter HH:MM 9999
```

NOTE: If you enter an invalid time the error tone will sound.

8.1.8 Changing the Brightness of the LCD keypad

To change the LCD brightness

- From the User Function menu use the shortcut key **1** **2** or press **<** **>** to scroll to Bright Control and press **#**
- Enter the 2 digit value or scroll to the desired brightness level and press **#** to return to the previous menu.
- Press **#** to return to the Ready state.

LCD Display

```
Press (*) for <>
Bright Control
```

```
Brightness <>
Level... XX
```

8.1.9 Changing the Contrast of the LCD keypad

To change the LCD contrast

- From the User Function menu use the shortcut key **1** **3** or press **<** **>** to scroll to Contrast Control and press **#**
- Enter the 2 digit value or scroll to the desired contrast level and press **#** to return to the previous menu.
- Press **#** to return to the Ready state.

LCD Display

```
Press (*) for <>
Contrast Control
```

```
Contrast <>
Level... XX
```

8.1.10 Setting the Buzzer volume

To change Buzzer volume

- From the User Function menu use the shortcut key **1** **4** or press **<** **>** to scroll to Contrast Control and press **#**
- Enter the 2 digit value or scroll to the desired volume level and press **#** to return to the previous menu.
- Press **#** to return to the Ready state.

LCD Display

```
Press (*) for <>
Buzzer Control
```

```
Buzzer <>
Level... XX
```

8.1.11 Setting the Voice Prompt volume

This feature is only available when using an HS2LCDWFPV wireless keypad.

To change Voice Prompt volume

- From the User Function menu use the shortcut key **1** **5** or press **<** **>** to scroll to Voice Prompt and press **#**
- Enter the 2 digit value or scroll to the desired volume level and press **#** to return to the previous menu.
- Press **#** to return to the Ready state.

LCD Display

```
Press (*) for <>
Voice Prompt
```

```
Voice Prompt <>
Level... XX
```

8 Configuring User Functions

8.1.12 Setting the Voice Chime volume

This feature is only available when using an HS2LCDWFPV wireless keypad.

To change Voice Chime volume

1. From the User Function menu use the shortcut key **1** **6** or press **<** **>** to scroll to Voice Chime and press **#**
2. Enter the 2 digit value or scroll to the desired volume level and press **#** to return to the previous menu.
3. Press **#** to return to the Ready state.

LCD Display

```
Press (*) for <>
Voice Chime
```

```
Voice Chime <>
Level... XX
```

9 Managing Troubles

9.1 Trouble Conditions

Trouble Conditions (Level 1) are comprised of various trouble types (Level 2) which may in turn be related to a specific zone, module, device or additional type of system equipment (Level 3). For an explanation of possible trouble conditions and the recommended actions required see Table 9-1.

When the system detects a trouble condition the following occurs:

- The Trouble indicator  turns on.
- The keypad beeps once every 10 seconds.
- Press the  key to silence the keypad beeps.

Examining troubles is done by pressing  . When viewing troubles, the trouble indicator  flashes to identify the level of trouble being viewed. One flash = level 1, two flashes = level 2 etc.

Table 9-1 Trouble Conditions

Trouble Condition	Trouble #	Description	Trouble Types	Trouble #	Trouble Notification
Level 1			Level 2		Level 3
NOTE: Trouble #s are used to identify the number to view the trouble and depending on the keypad type being used, identifies which LED or digit illuminates to display the trouble. Similarly, Trouble Notification identifies the range that may be displayed on the keypad. When exploring the trouble levels, the Trouble indicator  will flash to identify which level you are currently viewing.					
Service Required	01	Assorted Trouble types. Time and Date troubles can be resolved by resetting the Time/Date. To set Time/Date press     . For all other troubles call for service.	Bell Circuit	01	
			RF Jam	02	
			Auxiliary Supply	03	
			Time and Date	04	
			Output 1 Fault	05	
Battery Trouble	02	The system has detected a battery trouble condition. Call for service.	Low Battery (System Label)	01	n/a
			No Battery service. (System Label)	02	n/a
			High Current Output Low Battery	04	Module 1-4
			High Current Output No Battery	05	Module 1-4
			Power Supply Low Battery	07	Module 1-4
			Power Supply No Battery	08	Module 1-4
Bus Voltage	03	The system has detected a trouble condition. Call for service.	HSM2HOST	01	n/a
			Keypad	02	Keypad 1-16
			Zone Expander	04	Zone expander 1-15
			Power Supply	05	Power supply 1-4
			High Current Output	06	Output terminal 1-4
			Output Expander	08	Output module 1-16
AC Troubles	04	The system is experiencing loss of power. Call for service. If the building and/or neighborhood has lost electrical power, the system will continue to operate on battery for several hours.	Zone	01	Zone label or 001-128
			Siren	03	Siren 1-16
			Repeater	04	Repeater 1-8
			Power Supply	05	Power supply 1-4
			High Current Output	06	Output terminal 1-4
			System Label	07	n/a

9 Managing Troubles

Table 9-1 Trouble Conditions (Continued)

Trouble Condition	Trouble #	Description	Trouble Types	Trouble #		Trouble Notification		
				Level 1	Level 2		Level 3	
Device Faults	05	The system has detected an issue with one or more connected devices. Call for service.	Gas					
			Heat					
			CO					
			Freeze					
			Probe Disconnected					
			Fire					
			Zone				01	Zone label or 001-128
			Keypad				02	Keypad 1-16
			Siren				03	Siren 1-16
Repeater	04	Repeater 1-8						
Device Battery	06	The system has detected an issue with one or more of the device batteries. For Zone, Keypad and Wireless Key battery troubles see the accompanying documentation for how to change the batteries. For all other troubles call for service.	Zone	01	Zone label or 001-128			
			Keypad	02	Keypad 1-16			
			Siren	03	Siren 1-16			
			Repeater	04	Repeater 1-8			
			User	05	Wireless key 1-32			
Device Tamper	07	The system has detected a tamper condition with one or more devices on the system. Call for service.	Gas					
			Heat					
			CO					
			Freeze					
			Probe Disconnected					
			Fire					
			Zone				01	Zone label or 001-128
			Keypad				02	Keypad 1-16
			Siren				03	Siren 1-16
Repeater	04	Repeater 1-8						
RF Delinquency	08	The system has detected wireless signal interference that is causing improper system operation. Call for service.	Zones	01	Zone label or 001-128			
			Keypad	02	Keypad 1-16			
			Siren	03	Siren 1-16			
			Repeater	04	Repeater 1-8			
Module Supervision	09	The system has detected a supervisory trouble condition with one or more modules on the system. Call for service.	HSM2HOST	01	n/a			
			Keypad	02	Keypad 1-16			
			Zone Expander	04	Zone Expander 1-15			
			Power Supply	05	Power supply 1-4			
			High Current Output	06	Output terminal 1-4			
			Output Expander	08	Output module 1-16			
Module Tamper	10	The system has detected a tamper condition with one or more modules on the system. Call for service.	HSM2HOST	01	n/a			
			Keypad	02	Keypad 1-16			
			Zone Expander	04	Zone Expander 1-15			
			Power Supply	05	Power supply 1-4			
			High Current Output	06	Output terminal 1-4			
			Output Expander	08	Output module 1-16			

9 Managing Troubles

Table 9-1 Trouble Conditions (Continued)

Trouble Condition	Trouble #	Description	Trouble Types	Trouble #		Trouble Notification
				Level 1	Level 2	
Communications	11	The system has detected a communication trouble. Call for service.	TLM Trouble	01	n/a	
			FTC Trouble	02	Phone Number 1-4	
			SIM Lock	03	n/a	
			Cellular	04	n/a	
			Ethernet	05	n/a	
			Receiver	06	Receiver 1-4	
			Supervision	07	Supervision 1-4	
			Alternate Communicator FTC	10	Receiver 1-4	
Not Networked	12	The system has detected a network trouble condition with one or more modules on the system. Call for service.	Zone	01	Zone label 001-128	
			Keypad	02	Keypad 1-16	
			Siren	03	Siren 1-16	
			Repeater	04	Repeater 1-8	
			User	05	Users 01-95	

10 Managing Partitions

A partition is a limited area of the premises which operates independently from the other areas.

Partitioning a system can be beneficial if the property has outbuildings that need to be secured independently of a main area or if the home has a separate apartment.

Each partition can have its own keypad, or a keypad can have access to all partitions. User access to partitions is controlled via access code. A master code can access the entire system and partitions, while a user code is limited to assigned partitions.

10.1 Partitions

Keypads can be configured to control an individual partition or all partitions.

NOTE: Access to this feature must be configured by installer.

10.1.1 Single Partition Operation

Single partition keypads provide access to alarm functionality for an assigned partition.

Single partition keypads behave as follows:

- Displays the armed state of the partition.
- Displays open zones, if assigned to the partition the keypad is on.
- Displays bypassed zones and allows zone bypassing or creating bypass groups of zones assigned to the keypad partition.
- Displays system troubles (system low battery, system component faults/tampers).
- Displays alarms in memory that occurred on the partition.
- Allows the door chime to be Enabled/disabled.
- System test (sounds bells/PGMs assigned to the partition).
- Label programming (zone, partition and user labels for the partition).
- Command output controls (outputs assigned to the partition, or global outputs such as smoke detector reset).
- Temperatures.

10.1.2 Loaning a Keypad to Another Partition

Keypads can be loaned to operate on other partitions. When a keypad is loaned from either the global state or from another partition, it may be configured to behave on the loaned partition just as it would if it was originally assigned there.

Loaning a keypad to another partition does not require an access code; However, no function that requires an access code can be performed on that partition unless the user's code has sufficient permissions. The status of each partition will be identified by a partition flag. For an explanation on partition flags see Table 10-1.

To Loan a Keypad to Another Partition

1. Press and hold  for 2 seconds.
2. Select a partition by pressing digits 1 to 8. The keypad is temporarily loaned to another partition. If the keypad is inactive for more than 30 seconds, it reverts to its original mode.

LCD Display

1	2	3	4	5	6	7	8
R	R	-	-	-	-	-	N

Table 10-1 Partition Flags

LCD Display	Flag	Description
1 2 3 4 5 6 7 8 R R A ! - - - N	1-8	Partition number.

10 Managing Partitions

Table 10-1 Partition Flags (Continued)

LCD Display	Flag	Description
	R	Partition is ready to be armed.
	N	Partition is not ready to be armed.
	!	Partition is in alarm.
	-	Partition is not configured
	A	Partition is armed.

10.2 Fire and CO Zone Types

- If a Fire zone generates an alarm only the partition the fire zone is assigned to will go into alarm. Other partitions retain their current state.
- If the [F] key on a global keypad is used to generate an alarm all enabled partitions will go into alarm.
- One or more fire keypads may be located on any partition.
- On alarm, the fire auto-scroll display appears on all partition keypads and on all global keypads. Fire alarm silence and fire system reset may be done directly on any partition keypad. To silence a fire or CO alarm from a global keypad requires that the global keypad be loaned to one of the partitions.

11 Additional Features

11.1 Turning the Chime ON/OFF

Turning the chime on audibly notifies you whenever an entry/exit sensor is tripped.

To turn the Chime ON or OFF

- Press **(*)** **(4)** to toggle the Chime ON or OFF for the current partition.

LCD Display

Door Chime Feature ON

Door Chime Feature OFF

11.2 Audio Verification

Allows the monitoring station to initiate a 2-way audio (talk/listen) or 1-way audio (listen-in only) session when an alarm has been received. This feature is used to verify the nature of the alarm or determine the type of assistance required by the occupant.

NOTES: This is a supplementary feature that has not been investigated by UL/ULC.
Must be enabled and configured by installer.

11.3 Visual Verification

Allows the monitoring station to use video clips captured from system motion cameras for verification of any alarms.

NOTES: This is a supplementary feature that has not been investigated by UL/ULC.
Must be enabled and configured by installer.

11.3.1 System Lockout due to Invalid Attempts

If too many invalid access codes are entered, your system can be configured to automatically lock out inputs from all keypads, wireless and proximity keys, and SMS commands for a specified duration. When any keys are pressed, an error tone will sound. FMP keys are still active during Keypad Lockout.

NOTE: Feature and lockout duration must be configured by installer.

11.4 Command Outputs

While being useful for many applications, Command outputs are typically configured to operate items such as garage doors or electric gates. Additionally, Command outputs can be assigned to follow a schedule configured by your installer.

NOTES: This is a supplementary feature that has not been investigated by UL/ULC.
Must be configured by installer.

To Activate a Command Output

1. Press **(*)** **(7)** and if required enter your [access code].

OR

press **(*)** and use the scroll keys **(<)** **(>)** to navigate to Output Control.

2. Press the number configured to the command output

OR

use the scroll keys **(<)** **(>)** to navigate to the desired command output and press **(*)**.

LCD Display

Output Control <> Scroll to View

Output Activated

11 Additional Features

To configure a Command Output to Follow a Schedule

1. Press ***** **7** and use the scroll keys **<** **>** to navigate to Follow Schedule and press *****

OR

press ***** **7** **9**.

2. Press the command output #(1-4) to toggle scheduling and if required enter your [access code]

OR

use the scroll keys **<** **>** to navigate to the desired command output and press ***** to toggle scheduling and if required enter your [access code].

LCD Display

```
Output Control <>
Scroll to View
```

then

```
Press (*) to
Follow Schedule
```

```
Partition 1 <>
Command O/P 1 Y
```

11.5 Cross Zoning

The Control Panel includes the cross zone option that requires a trip on two zones within a given time period, to start an alarm transmission sequence.

NOTE: Must be enabled and configured by installer.

11.6 Swinger Shutdown

The Control Panel has a swinger shutdown feature that when enabled for CP-01 installation, a programmable number of trips shall shut down the zone.

NOTE: Must be enabled and configured by installer.

11.7 Call Waiting

The Control Panel includes a programmable option for call waiting to prevent a call waiting line from interfering with the alarm verification process. This option is disabled by default.

NOTE: Must be enabled and configured by installer.

11.8 Fire Alarm Verification

Fire Alarm Verification is an available option for Fire zones. If configured, once the conditions for alarm verification are met the fire alarm will sound and an alarm transmission will be sent to the monitoring station.

NOTE: Must be enabled and configured by installer.

12 Regulatory Agency Statements

FCC COMPLIANCE STATEMENT

CAUTION: Changes or modifications not expressly approved by Digital Security Controls could void your authority to use this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.

- Consult the dealer or experienced radio/television technician for help. The user may find the following booklet prepared by the FCC useful: "How to Identify and Resolve Radio/Television Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402, Stock # 004-000-00345-4.

The keypad represented in this manual can be used with the following Control Units: HS2016, HS2032, HS2064, HS2128.

IMPORTANT INFORMATION

This equipment complies with Part 68 of the FCC Rules and, if the product was approved July 23, 2001 or later, the requirements adopted by the ACTA. On the side of this equipment is a label that contains, among other information, a product identifier. If requested, this number must be provided to the Telephone Company.

HS2016 Product Identifier US:F53AL01BHS2128

HS2032 Product Identifier US:F53AL01BHS2128

HS2064 Product Identifier US:F53AL01BHS2128

HS2128 Product Identifier US:F53AL01BHS2128

USOC Jack: RJ-31X

Telephone Connection Requirements

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Ringier Equivalence Number (REN)

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local Telephone Company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US: AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is REN of 0.3). For earlier products, the REN is separately shown on the label.

Incidence of Harm

If this equipment (HS2016, HS2032, HS2064, HS2128) causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the Telephone Company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

Changes in Telephone Company Equipment or Facilities

The Telephone Company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the Telephone Company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

Equipment Maintenance Facility

If trouble is experienced with this equipment (HS2016, HS2032, HS2064, HS2128) for repair or warranty information, contact the facility indicated below. If the equipment is causing harm to the telephone network, the Telephone Company may request that you disconnect the equipment until the problem is solved. This equipment is of a type that is not intended to be repaired by the end user.


DSC c/o APL Logistics 757 Douglas Hill Rd, Lithia Springs, GA 30122

Additional Information

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

Alarm dialing equipment must be able to seize the telephone line and place a call in an emergency situation. It must be able to do this even if other equipment (telephone, answering system, computer modem, etc.) already

has the telephone line in use. To do so, alarm dialing equipment must be connected to a properly installed RJ-31X jack that is electrically in series with and ahead of all other equipment attached to the same telephone line. Proper installation is depicted in the figure below. If you have any questions concerning these instructions, you should consult your telephone company or a qualified installer about installing the RJ-31X jack and alarm dialing equipment for you.



Hersby, DSC, deklarerer at dette udstyr er i overensstemmelse med de væsentlige krav og andre relevante bestemmelser i Direktiv 1999/5/EC. The complete R&TTE Declaration of Conformity can be found at http://www.dsc.com/listings_index.aspx

(CZE) DSC jako výrobce prohlašuje, že tento výrobek je v souladu se všemi relevantními požadavky směrnice 1999/5/EC.

(DAN) DSC erklærer herved at denne komponent overholder alle vigtige krav samt andre bestemmelser gældende i direktiv 1999/5/EC.

(FIN) DSC vakuuttaa laitteen täyttävän direktiivin 1999/5/EC edellyttämät vaatimukset.

(FRE) Par la présente, DSC déclare que ce dispositif est conforme aux exigences essentielles et autres stipulations pertinentes de la Directive 1999/5/EC.

(GER) Hierdurch erklärt DSC, daß dieses Gerät den erforderlichen Bedingungen und Voraussetzungen der Richtlinie 1999/5/EC entspricht.

(GRE) Διο του προϊόντος, η DSC, δηλώνει ότι αυτή η συσκευή είναι σύμφωνα με τις ουσιώδεις απαιτήσεις και με άλλες σχετικές απαιτήσεις της Οδηγίας 1999/5/EC.

(ITA) Con la presente la Digital Security Controls dichiara che questo prodotto è conforme ai requisiti essenziali ed altre disposizioni rilevanti relative alla Direttiva 1999/5/CE.

(NOR) DSC erklærer at denne enheten er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

(POL) DSC oświadczca, że urządzenie jest w zgodności z zasadniczymi wymaganiami oraz pozostałymi istotowymi postanowieniami Dyrektywy 1999/5/WE.

(POR) Por este meio, a DSC, declara que este equipamento está em conformidade com os requisitos essenciais e outras determinações relevantes da Directiva 1999/5/CE.

(SPA) Por la presente, DSC, declara que este equipo está en conformidad con los requisitos esenciales y otros requisitos relevantes de la Directiva 1999/5/EC.

(SWE) DSC bekräftar härmed att denna apparat uppfyller de väsentliga kraven och andra relevanta bestämmelser i Direktivet 1999/5/EC.



12 Regulatory Agency Statements

INDUSTRY CANADA STATEMENT

NOTICE: The models: HS2128, HS2064, HS2032, HS2016 meet the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is 0.1. The REN applies to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all devices does not exceed 5.

HS2016 Registration number IC:160A-HS2128
HS2032 Registration number IC:160A-HS2128
HS2064 Registration number IC:160A-HS2128
HS2128 Registration number IC:160A-HS2128

This product is in conformity with EMC Directive 2004/108/EC based on results using harmonized standards in accordance with article 10(5), R&TTE Directive 1999/5/EC based on following Annex III of the directive and LVD Directive 2006/95/EC based on results using harmonized standards.

This product meets the requirements of Class II, Grade 2 equipment as per EN 50131-1:2006 + A1:2009 Standard. This product is suitable for use in systems with the following notification options:

- A (use of two warning devices and internal dialer required),
- B (self powered warning device and internal dialer required),
- C (internal dialer and alternate IP/3G communicator required)
- D (use of alternate IP/GSM communicator with encryption enabled required).

The Model HS2016, HS2032, HS2064, HS2128

Control Panel has been certified by Telefication according to EN50131-1:2006 + A1:2009, EN50131-3:2009, EN50131-6:2008 and EN50136-1:1997 for Grade 2, Class II, ATSE.

FCC AND INDUSTRY CANADA STATEMENTS FOR WIRELESS KEYPADS

Models: HS2LCDRF9, HS2LCDRFP9, HS2ICNRF9, HS2ICNRF9P9 (operating in 912-919MHz band) are compliant with applicable FCC Part 15.247 and IC RSS-210 rules.

WARNING! To comply with FCC and IC RF exposure compliance requirements, the HS2LCDRF(P)9 or HS2ICNRF(P)9 keypads should be located at a distance of at least 20 cm from all persons during normal operation. The antennas used for this product must not be co-located or operated in conjunction with any other antenna or transmitter.

This device complies with FCC Rules Part 15 and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received or that may cause undesired operation.

IC:160A – HS2KRF9P9

The term "IC" before the radio certification number only signifies that Industry Canada technical specifications were met.

AVERTISSEMENT! Pour répondre aux exigences de conformité de la FCC et d'Industrie Canada sur les limites d'exposition aux radiofréquences (RF), les pavés numériques HS2LCDRF(P)9 ou HS2ICNRF(P)9 doivent être installés à une distance minimale de 20 cm de toute personne lors de leur fonctionnement usuel. Ces derniers ne doivent pas être situés au même endroit, ni être en fonction avec une autre antenne ou un autre transmetteur.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The following is a list of warnings applicable when this equipment is connected to the New Zealand Telecom Network.

GENERAL WARNING

The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

REVERSE NUMBERING (DECADIC SIGNALLING)

Decadic signaling should not be used as it is being progressively phased out of the network. DTMF dialling is 100% available and it should always be used.

LINE GRABBING EQUIPMENT

This equipment is set up to carry out test calls at pre-determined times. Such test calls will interrupt any other calls that may be set up on the line at the same time. The timing set for such test calls should be discussed with the installer. The timing set for test calls from this equipment may be subject to 'drift'. If this proves to be inconvenient and your calls are interrupted, then the problem of timing should be discussed with the equipment installer. The matter should NOT be reported as a fault to Telecom Faults Service.

D.C. LINE FEED TO OTHER DEVICES

During dialing, this device unit does not provide DC voltage to the series port connection and this may cause loss of memory functions for the terminal devices (local telephone) connected to T-1, R-1.

General operation (ringer sensitivity and loading)

This device only responds to Distinctive Alert cadences DA1 and DA2.

In the event of any problem with this device, it is to be disconnected. A CPE item connected to one of the device's terminal ports may be connected directly in its place. The user should then arrange for the product to be repaired. The matter to be reported to Telecom as a wiring fault, and the fault is proven to be due to this product, a call-out charge will be incurred.

13 Installer Warning

WARNING Please Read Carefully

Note to Installers

This warning contains vital information. As the only individual in contact with system users, it is your responsibility to bring each item in this warning to the attention of the users of this system.

System Failures

This system has been carefully designed to be as effective as possible. There are circumstances, however, involving fire, burglary, or other types of emergencies where it may not provide protection. Any alarm system of any type may be compromised deliberately or may fail to operate as expected for a variety of reasons. Some but not all of these reasons may be:

Inadequate Installation

A security system must be installed properly in order to provide adequate protection. Every installation should be evaluated by a security professional to ensure that all access points and areas are covered. Locks and latches on windows and doors must be secure and operate as intended. Windows, doors, walls, ceilings and other building materials must be of sufficient strength and construction to provide the level of protection expected. A reevaluation must be done during and after any construction activity. An evaluation by the fire and/or police department is highly recommended if this service is available.

Criminal Knowledge

This system contains security features which were known to be effective at the time of manufacture. It is possible for persons with criminal intent to develop techniques which reduce the effectiveness of these features. It is important that a security system be reviewed periodically to ensure that its features remain effective and that it be updated or replaced if it is found that it does not provide the protection expected.

Access by Intruders

Intruders may enter through an unprotected access point, circumvent a sensing device, evade detection by moving through an area of insufficient coverage, disconnect a warning device, or interfere with or prevent the proper operation of the system.

Power Failure

Control units, intrusion detectors, smoke detectors and many other security devices require an adequate power supply for proper operation. If a device operates from batteries, it is possible for the batteries to fail. Even if the batteries have not failed, they must be charged, in good condition and installed correctly. If a device operates only by AC power, any interruption, however brief, will render that device inoperative while it does not have power. Power interruptions of any length are often accompanied by voltage fluctuations which may damage electronic equipment such as a security system. After a power interruption has occurred, immediately conduct a complete system test to ensure that the system operates as intended.

Failure of Replaceable Batteries

This system's wireless transmitters have been designed to provide several years of battery life under normal conditions. The expected battery life is a function of the device environment, usage and type. Ambient conditions such as high humidity, high or low temperatures, or large temperature fluctuations may reduce the expected battery life. While each transmitting device has a low battery monitor which identifies when the batteries need to be replaced, this monitor may fail to operate as expected. Regular testing and maintenance will keep the system in good operating condition.

Compromise of Radio Frequency (Wireless) Devices

Signals may not reach the receiver under all circumstances which could include metal objects placed on or near the radio path or deliberate jamming or other inadvertent radio signal interference.

System Users

A user may not be able to operate a panic or emergency switch possibly due to permanent or temporary physical disability, inability to reach the device in time, or unfamiliarity with the correct operation. It is important that all system users be trained in the correct operation of the alarm system and that they know how to respond when the system indicates an alarm.

Smoke Detectors

Smoke detectors that are a part of this system may not properly alert occupants of a fire for a number of reasons, some of which follow. The smoke detectors may have been improperly installed or

positioned. Smoke may not be able to reach the smoke detectors, such as when the fire is in a chimney, walls or roofs, or on the other side of closed doors. Smoke detectors may not detect smoke from fires on another level of the residence or building.

Every fire is different in the amount of smoke produced and the rate of burning. Smoke detectors cannot sense all types of fires equally well. Smoke detectors may not provide timely warning of fires caused by carelessness or safety hazards such as smoking in bed, violent explosions, escaping gas, improper storage of flammable materials, overloaded electrical circuits, children playing with matches or arson.

Even if the smoke detector operates as intended, there may be circumstances when there is insufficient warning to allow all occupants to escape in time to avoid injury or death.

Motion Detectors

Motion detectors can only detect motion within the designated areas as shown in their respective installation instructions. They cannot discriminate between intruders and intended occupants. Motion detectors do not provide volumetric area protection. They have multiple beams of detection and motion can only be detected in unobstructed areas covered by these beams. They cannot detect motion which occurs behind walls, ceilings, floor, closed doors, glass partitions, glass doors or windows. Any type of tampering whether intentional or unintentional such as masking, painting, or spraying of any material on the lenses, mirrors, windows or any other part of the detection system will impair its proper operation.

Passive infrared motion detectors operate by sensing changes in temperature. However their effectiveness can be reduced when the ambient temperature rises near or above body temperature or if there are intentional or unintentional sources of heat in or near the detection area. Some of these heat sources could be heaters, radiators, stoves, barbecues, fireplaces, sunlight, steam vents, lighting and so on.

Warning Devices

Warning devices such as sirens, bells, horns, or strobes may not warn people or waken someone sleeping if there is an intervening wall or door. If warning devices are located on a different level of the residence or premise, then it is less likely that the occupants will be alerted or awakened. Audible warning devices may be interfered with by other noise sources such as stereos, radios, televisions, air conditioners or other appliances, or passing traffic. Audible warning devices, however loud, may not be heard by a hearing-impaired person.

Telephone Lines

If telephone lines are used to transmit alarms, they may be out of service or busy for certain periods of time. Also an intruder may cut the telephone line or defeat its operation by more sophisticated means which may be difficult to detect.

Insufficient Time

There may be circumstances when the system will operate as intended, yet the occupants will not be protected from the emergency due to their inability to respond to the warnings in a timely manner. If the system is monitored, the response may not occur in time to protect the occupants or their belongings.

Component Failure

Although every effort has been made to make this system as reliable as possible, the system may fail to function as intended due to the failure of a component.

Inadequate Testing

Most problems that would prevent an alarm system from operating as intended can be found by regular testing and maintenance. The complete system should be tested weekly and immediately after a break-in, an attempted break-in, a fire, a storm, an earthquake, an accident, or any kind of construction activity inside or outside the premises. The testing should include all sensing devices, keypads, consoles, alarm indicating devices and any other operational devices that are part of the system.

Security and Insurance

Regardless of its capabilities, an alarm system is not a substitute for property or life insurance. An alarm system also is not a substitute for property owners, renters, or other occupants to act prudently to prevent or minimize the harmful effects of an emergency situation.

14 Safety Instructions

WARNING: This equipment has no mains on/off switch. the plug of the direct plug-in power supply is intended to serve as the disconnecting device if the equipment must be quickly disconnected. it is imperative that access to the mains plug and associated mains socket/outlet, is never obstructed.

WARNING: When using equipment connected to the mains and/or to the telecommunication network, there are basic safety instructions that should always be followed. Refer to the safety instructions provided with this product and save them for future reference. To reduce the risk of fire, electric shock and/or injury, observe the following:

- Do not attempt to service this product yourself. Opening or removing the cover may expose you to dangerous voltage or other risk. Refer servicing to qualified service persons. Never open the device yourself.
- Any servicing shall be referred to Service Persons only.
- Dispose the used batteries according to the local rules and regulations.
- Do not leave and/or deposit any object on the top of the equipment cabinet. The cabinet, as installed, is not designed to support any supplementary weight.
- Do not spill any liquids on the cabinet.
- Do not touch the equipment and its connected cables during an electrical storm; there may be a risk of electric shock.
- Never touch uninsulated wires or terminals unless the Direct Plug In transformer has been disconnected.
- Ensure that cables are positioned so that accidents cannot occur. Connected cables must not be subject to excessive mechanical strain. Do not spill any type of liquid on the equipment.
- Do not use the Alarm system to report a gas leak if the system is near a leak.
- The equipment is stationary/ fixed and direct plug-in connected to the mains and shall be installed and serviced by service persons only.

14.1 Regular Maintenance and Troubleshooting

Keep your Alarm Controller in optimal condition by following all the instructions that are included within this manual and/or marked on the product.

14.1.1 Cleaning

- Clean the units by wiping with a damp cloth only.
- Do not use abrasives, thinners, solvents or aerosol cleaners (spray polish) that may enter through holes in the Alarm Controller and cause damage.
- Do not use any water or any other liquid.
- Do not wipe the front cover with alcohol.

14.1.2 Troubleshooting

Occasionally, you may have a problem with your Alarm Controller or telephone line. If this happens, your Alarm Controller will identify the problem and displays an error message. Refer to the provided list when you see an error message on the display. If additional help is required, contact your distributor for service.

NOTE: There are no parts replaceable by the end-user within this equipment, except for the keypad batteries. Dispose of used batteries as per local rules and regulations.

This publication covers the following models x = 9 (912-919MHz UL/ULC systems), 4 (433MHz) or 8 (868MHz).

- | | | | |
|----------|--------------|---------------|-------------|
| • HS2016 | • HS2LCD | • HS2LCDWFx | • HS2ICN |
| • HS2128 | • HS2LCDP | • HS2LCDWFPx | • HS2ICNP |
| • HS2032 | • HS2LCDRFx | • HS2LCDWFPVx | • HS2ICNRFx |
| • HS2064 | • HS2LCDRFPx | • HS2LED | • HS2ICNRFx |

15 EULA

IMPORTANT - READ CAREFULLY: DSC Software purchased with or without Products and Components is copyrighted and is purchased under the following license terms:

- This End-User License Agreement ("EULA") is a legal agreement between You (the company, individual or entity who acquired the Software and any related Hardware) and Digital Safety Controls, a division of Tyco Safety Products Canada Ltd. ("DSC"), the manufacturer of the integrated security systems and the developer of the software and any related products or components ("HARDWARE") which You acquired.
- If the DSC software product ("SOFTWARE PRODUCT" or "SOFTWARE") is intended to be accompanied by HARDWARE, and is NOT accompanied by new HARDWARE, You may not use, copy or install the SOFTWARE PRODUCT. The SOFTWARE PRODUCT includes computer software, and may include associated media, printed materials, and "online" or electronic documentation.
- Any software provided along with the SOFTWARE PRODUCT that is associated with a separate end-user license agreement is licensed to You under the terms of that license agreement.
- By installing, copying, downloading, storing, accessing or otherwise using the SOFTWARE PRODUCT, You agree unconditionally to be bound by the terms of this EULA, even if this EULA is deemed to be a modification of any previous arrangement or contract. If You do not agree to the terms of this EULA, DSC is unwilling to license the SOFTWARE PRODUCT to You, and You have no right to use it.

The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE PRODUCT is licensed, not sold.

1. GRANT OF LICENSE This EULA grants You the following rights:
 - (a) Software Installation and Use - For each license You acquire, You may have only one copy of the SOFTWARE PRODUCT installed.
 - (b) Storage/Network Use - The SOFTWARE PRODUCT may not be installed, accessed, displayed, run, shared or used concurrently on or from different computers, including a workstation, terminal or other digital electronic device ("Device"). In other words, if You have several workstations, You will have to acquire a license for each workstation where the SOFTWARE will be used.
 - (c) Backup Copy - You may make back-up copies of the SOFTWARE PRODUCT, but You may only have one copy per license installed at any given time. You may use the back-up copy solely for archival purposes. Except as expressly provided in this EULA, You may not otherwise make copies of the SOFTWARE PRODUCT, including the printed materials accompanying the SOFTWARE.
2. DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS
 - (a) Limitations on Reverse Engineering, Decompilation and Disassembly - You may not reverse engineer, decompile, or disassemble the SOFTWARE PRODUCT, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. You may not make any changes or modifications to the Software, without the written permission of an officer of DSC. You may not remove any proprietary notices, marks or labels from the Software Product. You shall institute reasonable measures to ensure compliance with the terms and conditions of this EULA.
 - (b) Separation of Components - The SOFTWARE PRODUCT is licensed as a single product. Its component parts may not be separated for use on more than one HARDWARE unit.
 - (c) Single INTEGRATED PRODUCT - If You acquired this SOFTWARE with HARDWARE, then the SOFTWARE PRODUCT is licensed with the HARDWARE as a single integrated product. In this case, the SOFTWARE PRODUCT may only be used with the HARDWARE as set forth in this EULA.
 - (d) Rental - You may not rent, lease or lend the SOFTWARE PRODUCT. You may not make it available to others or post it on a server or web site.
 - (e) Software Product Transfer - You may transfer all of Your rights under this EULA only as part of a permanent sale or transfer of the HARDWARE, provided You retain no copies, You transfer all of the SOFTWARE PRODUCT (including all component parts, the media and printed materials, any upgrades and this EULA), and provided the recipient agrees to the terms of this EULA. If the SOFTWARE PRODUCT is an upgrade, any transfer must also include all prior versions of the SOFTWARE PRODUCT.
 - (f) Termination - Without prejudice to any other rights, DSC may terminate this EULA if You fail to comply with the terms and conditions of this EULA. In such event, You must destroy all copies of the SOFTWARE PRODUCT and all of its component parts.
 - (g) Trademarks - This EULA does not grant You any rights in connection with any trademarks or service marks of DSC or its suppliers.
3. COPYRIGHT - All title and intellectual property rights in and to the SOFTWARE PRODUCT (including but not limited to any images, photographs, and text incorporated into the SOFTWARE PRODUCT), the accompanying printed materials, and any copies of the SOFTWARE PRODUCT, are owned by DSC or its suppliers. You may not copy the printed materials accompanying the SOFTWARE PRODUCT. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE PRODUCT are the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants You no rights to use such content. All rights not expressly granted under this EULA are reserved by DSC and its suppliers.
4. EXPORT RESTRICTIONS - You agree that You will not export or re-export the SOFTWARE PRODUCT to any country, person, or entity subject to Canadian export restrictions.
5. CHOICE OF LAW - This Software License Agreement is governed by the laws of the Province of Ontario, Canada.

6. ARBITRATION - All disputes arising in connection with this Agreement shall be determined by final and binding arbitration in accordance with the Arbitration Act, and the parties agree to be bound by the arbitrator's decision. The place of arbitration shall be Toronto, Canada, and the language of the arbitration shall be English.

7. LIMITED WARRANTY

- (a) NO WARRANTY - DSC PROVIDES THE SOFTWARE "AS IS" WITHOUT WARRANTY. DSC DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE.
- (b) CHANGES IN OPERATING ENVIRONMENT - DSC shall not be responsible for problems caused by changes in the operating characteristics of the HARDWARE, or for problems in the interaction of the SOFTWARE PRODUCT with non-DSC SOFTWARE or HARDWARE PRODUCTS.
- (c) LIMITATION OF LIABILITY; WARRANTY REFLECTS ALLOCATION OF RISK - IN ANY EVENT, IF ANY STATUTE IMPLIES WARRANTIES OR CONDITIONS NOT STATED IN THIS LICENSE AGREEMENT, DSC'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS LICENSE AGREEMENT SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU TO LICENSE THE SOFTWARE PRODUCT AND FIVE CANADIAN DOLLARS (CAD\$5.00). BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.
- (d) DISCLAIMER OF WARRANTIES - THIS WARRANTY CONTAINS THE ENTIRE WARRANTY AND SHALL BE IN LIEU OF ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF DSC. DSC MAKES NO OTHER WARRANTIES. DSC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON PURPORTING TO ACT ON ITS BEHALF TO MODIFY OR TO CHANGE THIS WARRANTY, NOR TO ASSUME FOR IT ANY OTHER WARRANTY OR LIABILITY CONCERNING THIS SOFTWARE PRODUCT.
- (e) EXCLUSIVE REMEDY AND LIMITATION OF WARRANTY - UNDER NO CIRCUMSTANCES SHALL DSC BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF THE SOFTWARE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF SUBSTITUTE OR REPLACEMENT EQUIPMENT, FACILITIES OR SERVICES, DOWNTIME, PURCHASERS TIME, THE CLAIMS OF THIRD PARTIES, INCLUDING CUSTOMERS, AND INJURY TO PROPERTY.

WARNING: DSC recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this SOFTWARE PRODUCT to fail to perform as expected.

Always ensure you obtain the latest version of the User Guide. Updated versions of this User Guide are available by contacting your distributor.

New Zealand Telecom Network

The following is a list of warnings applicable when this equipment is connected to the New Zealand Telecom Network.

General Warning

The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

Reverse Numbering (decadic signalling)

Decadic signalling should not be used as it is being progressively phased out of the network. DTMF dialling is 100% available and it should always be used.

Line Grabbing Equipment

This equipment is set up to carry out test calls at pre-determined times. Such test calls will interrupt any other calls that may be set up on the line at the same time. The timing set for such test calls should be discussed with the installer. The timing set for test calls from this equipment may be subject to 'drift'. If this proves to be inconvenient and your calls are interrupted, then the problem of timing should be discussed with the equipment installer. The matter should NOT be reported as a fault to Telecom Faults Service.

D.C. Line Feeds to Other Devices

During dialling, this device unit does not provide DC voltage to the series port connection and this may cause loss of memory functions for the terminal devices (local telephone) connected to T-1, R-1.

General Operation (Ringer Sensitivity and Loading).

This device only responds to Distinctive Alert cadences DA1 and DA2

16 Locating Detectors and Escape Plan

The following information is for general guidance only and it is recommended that local fire codes and regulations be consulted when locating and installing smoke and CO alarms.

16.1 Smoke Detectors

Research has shown that all hostile fires in homes generate smoke to a greater or lesser extent. Experiments with typical fires in homes indicate that detectable quantities of smoke precede detectable levels of heat in most cases. For these reasons, smoke alarms should be installed outside of each sleeping area and on each storey of the home.

The following information is for general guidance only and it is recommended that local fire codes and regulations be consulted when locating and installing smoke alarms.

It is recommended that additional smoke alarms beyond those required for minimum protection be installed. Additional areas that should be protected include: the basement; bedrooms, especially where smokers sleep; dining rooms; furnace and utility rooms; and any hallways not protected by the required units. On smooth ceilings, detectors may be spaced 9.1 m (30 feet) apart as a guide. Other spacing may be required depending on ceiling height, air movement, the presence of joists, uninsulated ceilings, etc. Consult National Fire Alarm Code NFPA 72, CAN/ULC-S553-02 or other appropriate national standards for installation recommendations.

- Do not locate smoke detectors at the top of peaked or gabled ceilings; the dead air space in these locations may prevent the unit from detecting smoke.
- Avoid areas with turbulent air flow, such as near doors, fans or windows. Rapid air movement around the detector may prevent smoke from entering the unit.
- Do not locate detectors in areas of high humidity.
- Do not locate detectors in areas where the temperature rises above 38°C (100°F) or falls below 5°C (41°F).
- Smoke detectors should always be installed in USA in accordance with Chapter 11 of NFPA 72, the National Fire Alarm Code: 11.5.1.1.

Where required by applicable laws, codes, or standards for a specific type of occupancy, approved single- and multiple-station smoke alarms shall be installed as follows:

1. In all sleeping rooms and guest rooms.
2. Outside of each separate dwelling unit sleeping area, within 6.4 m (21 ft) of any door to a sleeping room, the distance measured along a path of travel.
3. On every level of a dwelling unit, including basements.
4. On every level of a residential board and care occupancy (small facility), including basements and excluding crawl spaces and unfinished attics.
5. In the living area(s) of a guest suite.
6. In the living area(s) of a residential board and care occupancy (small facility).




Figure 4

16 Locating Smoke and CO Detectors

16.2 Fire Escape Planning

There is often very little time between the detection of a fire and the time it becomes deadly. It is thus very important that a family escape plan be developed and rehearsed.

1. Every family member should participate in developing the escape plan.
2. Study the possible escape routes from each location within the house. Since many fires occur at night, special attention should be given to the escape routes from sleeping quarters.
3. Escape from a bedroom must be possible without opening the interior door.

Consider the following when making your escape plans:

- Make sure that all border doors and windows are easily opened. Ensure that they are not painted shut, and that their locking mechanisms operate smoothly.
- If opening or using the exit is too difficult for children, the elderly or handicapped, plans for rescue should be developed. This includes making sure that those who are to perform the rescue can promptly hear the fire warning signal.
- If the exit is above the ground level, an approved fire ladder or rope should be provided as well as training in its use.
- Exits on the ground level should be kept clear. Be sure to remove snow from exterior patio doors in winter; outdoor furniture or equipment should not block exits.
- Each person should know the predetermined assembly point where everyone can be accounted for (e.g., across the street or at a neighbor's house). Once everyone is out of the building, call the fire department.
- A good plan emphasizes quick escape. Do not investigate or attempt to fight the fire, and do not gather belongings as this can waste valuable time. Once outside, do not re-enter the house. Wait for the fire department.
- Write the fire escape plan down and rehearse it frequently so that should an emergency arise, everyone will know what to do. Revise the plan as conditions change, such as the number of people in the home, or if there are changes to the building's construction.
- Make sure your fire warning system is operational by conducting weekly tests. If you are unsure about system operation, contact your installer.

We recommend that you contact your local fire department and request further information on fire safety and escape planning. If available, have your local fire prevention officer conduct an in-house fire safety inspection.


16.3 Carbon Monoxide Detectors

Carbon monoxide is colorless, odorless, tasteless, and very toxic, it also moves freely in the air. CO detectors can measure the concentration and sound a loud alarm before a potentially harmful level is reached. The human body is most vulnerable to the effects of CO gas during sleeping hours; therefore, CO detectors should be located in or as near as possible to sleeping areas of the home. For maximum protection, a CO alarm should be located outside primary sleeping areas or on each level of your home. Figure 5 indicates the suggested locations in the home.

Do NOT place the CO alarm in the following areas:

- Where the temperature may drop below -10°C or exceed 40°C
- Near paint thinner fumes
- Within 5 feet (1.5m) of open flame appliances such as furnaces, stoves and fireplaces
- In exhaust streams from gas engines, vents, flues or chimneys
- Do not place in close proximity to an automobile exhaust pipe; this will damage the detector

PLEASE REFER TO THE CO DETECTOR INSTALLATION AND OPERATING INSTRUCTION SHEET FOR SAFETY INSTRUCTIONS AND EMERGENCY INFORMATION.



17 Reference

Fill out the following information for future reference and store this guide in a safe place.


17.1 System Information

Mark if Buttons are Enabled

[F] FIRE [M] Medical [P] PANIC



The Exit Delay Time is _____ seconds.



The Entry Delay Time is _____ seconds.

17.2 Service Contact Information

Central Station Information

Account#: _____ Telephone#: _____

Installer Information:

Company: _____ Telephone#: _____

Battery Installation / Service Date:

IMPORTANT: If you suspect a false alarm signal has been sent to the central monitoring station, call the station to avoid an unnecessary response.

17 Reference

17.3 Access Code and Sensor / Zone information

Master Code [01] : _____

Table 17-1 Access Code Reference Sheet

Code	Access Code						
01		13		25		37	
02		14		26		38	
03		15		27		39	
04		16		28		40	
05		17		29		41	
06		18		30		42	
07		19		31		43	
08		20		32		44	
09		21		33		45	
10		22		34		46	
11		23		35		47	
12		24		36		48	
49		55		61		67	
50		56		62		68	
51		57		63		69	
52		58		64		70	
53		59		65		71	
54		60		66		72	
73		79		85		91	
74		80		86		92	
75		81		87		93	
76		82		88		94	
77		83		89		95	
78		84		90			

17 Reference

Table 17-2 Sensor / Zone Information

Sensor	Protected Area	Sensor Type	Sensor	Protected Area	Sensor Type
01			34		
02			35		
03			36		
04			37		
05			38		
06			39		
07			40		
08			41		
09			42		
10			43		
11			44		
12			45		
13			46		
14			47		
15			48		
16			49		
17			50		
18			51		
19			52		
20			53		
21			54		
22			55		
23			56		
24			57		
25			58		
26			59		
27			60		
28			61		
29			62		
30			63		
31			64		
32			65		
33			66		

17 Reference

Table 17-2 Sensor / Zone Information

Sensor	Protected Area	Sensor Type	Sensor	Protected Area	Sensor Type
67			98		
68			99		
69			100		
70			101		
71			102		
72			103		
73			104		
74			105		
75			106		
76			107		
77			108		
78			109		
79			110		
80			111		
81			112		
82			113		
83			114		
84			115		
85			116		
86			117		
87			118		
88			119		
89			120		
90			121		
91			122		
92			123		
93			124		
94			125		
95			126		
96			127		
97			128		

© 2014 Tyco International Ltd. and its Respective Companies. All Rights Reserved.
Toronto, Canada • www.dsc.com •

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco International Ltd. will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco International Ltd. are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.

DSC[®]

A Tyco International Company



29008365R001